










Remove Cable cover





Remove Sun shield upper



Remove Cable case



Remove SD slot cover



Remove SD sun shield