

Control Commands

Model No. PT-FRQ50



- Please refer to the Operating Instructions for the serial command format, limitations, connection and other details.
- シリアルコマンドのフォーマット、制限事項、接続方法およびその他詳細につきましては、各モデルの取扱説明書をご覧ください。
- 有关串行控制命令的格式、限制事项、连接方法以及其他详情、请参阅各机型的使用说明书。

Panasonic

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		FRQ50 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK	FRQ50	
CONTROL		GREEN		VXX: GMGI 8=+00004		GMGI 8=+00004		✓
		BLUE		VXX: GMGI 8=+00005		GMGI 8=+00005		✓
		CYAN		VXX: GMGI 8=+00006		GMGI 8=+00006		✓
		MAGENTA		VXX: GMGI 8=+00007		GMGI 8=+00007		✓
		YELLOW		VXX: GMGI 8=+00008		GMGI 8=+00008		✓
	CONVERGENCE	OFF ON		VXX: CNVI 1=+00000 VXX: CNVI 1=+00001		QVX: CNVI 1 CNVI 1=+00000 CNVI 1=+00001		✓ ✓ ✓
	CONVERGENCE - UPPER LEFT VERTICAL			VXX: CNVS2=*: ***** VXX: CNVS2=R: ***** VXX: CNVS2=G: ***** VXX: CNVS2=B: ***** VXX: CNVS2=*: +00. 00 VXX: CNVS2=*: +03. 75		QVX: CNVS2 CNVS2=*: ***** CNVS2=R: ***** CNVS2=G: ***** CNVS2=B: ***** CNVS2=*: +00. 00 CNVS2=*: +03. 75		✓ ✓ ✓ ✓ ✓ ✓ ✓
	CONVERGENCE - UPPER LEFT HORIZONTAL			VXX: CNVS3=*: ***** VXX: CNVS3=R: ***** VXX: CNVS3=G: ***** VXX: CNVS3=B: ***** VXX: CNVS3=*: +00. 00 VXX: CNVS3=*: +03. 75		QVX: CNVS3 CNVS3=*: ***** CNVS3=R: ***** CNVS3=G: ***** CNVS3=B: ***** CNVS3=*: +00. 00 CNVS3=*: +03. 75		✓ ✓ ✓ ✓ ✓ ✓ ✓
	CONVERGENCE - UPPER RIGHT VERTICAL			VXX: CNVS4=*: ***** VXX: CNVS4=R: ***** VXX: CNVS4=G: ***** VXX: CNVS4=B: ***** VXX: CNVS4=*: +00. 00 VXX: CNVS4=*: +03. 75		QVX: CNVS4 CNVS4=*: ***** CNVS4=R: ***** CNVS4=G: ***** CNVS4=B: ***** CNVS4=*: +00. 00 CNVS4=*: +03. 75		✓ ✓ ✓ ✓ ✓ ✓ ✓
	CONVERGENCE - UPPER RIGHT HORIZONTAL			VXX: CNVS5=*: ***** VXX: CNVS5=R: ***** VXX: CNVS5=G: ***** VXX: CNVS5=B: ***** VXX: CNVS5=*: - 03. 75 VXX: CNVS5=*: +00. 00		QVX: CNVS5 CNVS5=*: ***** CNVS5=R: ***** CNVS5=G: ***** CNVS5=B: ***** CNVS5=*: - 03. 75 CNVS5=*: +00. 00		✓ ✓ ✓ ✓ ✓ ✓ ✓
	CONVERGENCE - LOWER LEFT VERTICAL			VXX: CNVS6=*: ***** VXX: CNVS6=R: ***** VXX: CNVS6=G: ***** VXX: CNVS6=B: ***** VXX: CNVS6=*: +00. 00 VXX: CNVS6=*: +03. 75		QVX: CNVS6 CNVS6=*: ***** CNVS6=R: ***** CNVS6=G: ***** CNVS6=B: ***** CNVS6=*: +00. 00 CNVS6=*: +03. 75		✓ ✓ ✓ ✓ ✓ ✓ ✓
	CONVERGENCE - LOWER LEFT HORIZONTAL			VXX: CNVS7=*: ***** VXX: CNVS7=R: ***** VXX: CNVS7=G: ***** VXX: CNVS7=B: ***** VXX: CNVS7=*: - 03. 75 VXX: CNVS7=*: +00. 00		QVX: CNVS7 CNVS7=*: ***** CNVS7=R: ***** CNVS7=G: ***** CNVS7=B: ***** CNVS7=*: - 03. 75 CNVS7=*: +00. 00		✓ ✓ ✓ ✓ ✓ ✓ ✓
	CONVERGENCE - LOWER RIGHT VERTICAL			VXX: CNVS8=*: ***** VXX: CNVS8=R: ***** VXX: CNVS8=G: ***** VXX: CNVS8=B: ***** VXX: CNVS8=*: - 03. 75 VXX: CNVS8=*: +00. 00		QVX: CNVS8 CNVS8=*: ***** CNVS8=R: ***** CNVS8=G: ***** CNVS8=B: ***** CNVS8=*: - 03. 75 CNVS8=*: +00. 00		✓ ✓ ✓ ✓ ✓ ✓ ✓
	CONVERGENCE - LOWER RIGHT HORIZONTAL			VXX: CNVS9=*: ***** VXX: CNVS9=R: ***** VXX: CNVS9=G: ***** VXX: CNVS9=B: ***** VXX: CNVS9=*: - 03. 75 VXX: CNVS9=*: +00. 00		QVX: CNVS9 CNVS9=*: ***** CNVS9=R: ***** CNVS9=G: ***** CNVS9=B: ***** CNVS9=*: - 03. 75 CNVS9=*: +00. 00		✓ ✓ ✓ ✓ ✓ ✓ ✓
	SHIFT-HORIZONTAL	0 +4095		VTH: 0000 VTH: 4095		QTH 4095		✓ ✓
	SHIFT-VERTICAL	0 +4094		VTV: 0000 VTV: 4094		QTV 4094		✓ ✓
	CLOCK PHASE	0 +31		VCP: 000 VCP: 031		QCP 063		✓ ✓
	ASPECT	AUTO/VID AUTO/DEFAULT NORMAL(4:3) WIDE(16:9) NATIVE(through) FULL(HV FIT) H-FIT V-FIT		VSE: 0 VSE: 1 VSE: 2 VSE: 5 VSE: 6 VSE: 9 VSE: 10		QSE 0 1 2 5 6 9 10		✓ ✓ ✓ ✓ ✓ ✓ ✓
	ZOOM-HORIZONTAL	50 999		OZH: 050 OZH: 999		QZH 050 999		✓ ✓ ✓
	ZOOM-VERTICAL	50 999		OZV: 050 OZV: 999		QZV 050 999		✓ ✓ ✓
	ZOOM-BOTH	50 999		OZO: 050 OZO: 999		QZO 050 999		✓ ✓ ✓
	ZOOM-INTERLOCKED	OFF ON		OZS: 0 OZS: 1		QZS 0 1		✓ ✓ ✓
	ZOOM-MODE	INTERNAL FULL		OZT: 0 OZT: 1		QZT 0 1		✓ ✓ ✓
	DIGITAL CINEMA REALITY	AUTO OFF 30p/25p FIXED		OPD: 0 OPD: 1 OPD: 2		QPD 0 1 2		✓ ✓ ✓ ✓
	BLANKING-UPPER	min. max.		DBU: 000 DBU: 2398		QLU 000 2398		0 2398
	BLANKING-LOWER	min. max.		DBB: 000 DBB: 2398		QLB 000 2398		0 2398
	BLANKING-RIGHT	min. max.		DBR: 000 DBR: 3838		QLR 000 3838		0 3838
	BLANKING-LEFT	min. max.		DBL: 000 DBL: 3838		QLL 000 3838		0 3838
	INPUT RESOLUTION-TOTAL DOTS	330 4095		VTD: 0330 VTD: 4095		QTD 0330 4095		✓ ✓
	INPUT RESOLUTION-DISPLAY DOTS	300 4065		VDD: 0300 VDD: 4065		QDD 0300 4065		✓ ✓
	INPUT RESOLUTION-TOTAL LINES	155 2047		VTL: 0155 VTL: 2047		QTL 0155 2047		✓ ✓
	INPUT RESOLUTION-DISPLAY LINES	150 2037		VDL: 0150 VDL: 2037		QDL 0150 2037		✓ ✓
	CLAMP POSITION	1 255		VLT: 001 VLT: 255		QLT 001 255		✓ ✓
	EDGE BLENDING	OFF ON USER		VXX: EDBI 0=+00000 VXX: EDBI 0=+00001 VXX: EDBI 0=+00002		QVX: EDBI 0 EDBI 0=+00000 EDBI 0=+00001 EDBI 0=+00002		✓ ✓ ✓ ✓
	EDGE BLENDING-UPPER ON/OFF	OFF ON		VGU: 0 VGU: 1		QGU 0 1		✓ ✓ ✓
	EDGE BLENDING-LOWER ON/OFF	OFF ON		VGB: 0 VGB: 1		QGB 0 1		✓ ✓ ✓
	EDGE BLENDING-LEFT ON/OFF	OFF ON		VGL: 0 VGL: 1		QGL 0 1		✓ ✓ ✓
	EDGE BLENDING-RIGHT ON/OFF	OFF ON		VGR: 0 VGR: 1		QGR 0 1		✓ ✓ ✓
	EDGE BLENDING-START-UPPER	min. max.		VEU: 0000 VEU: 2272		QEU 0000 2272		0 2272
	EDGE BLENDING-START-LOWER	min. max.		VEB: 0000 VEB: 2272		QEB 0000 2272		0 2272
EDGE BLENDING-START-LEFT	min. max.		VEL: 0000 VEL: 3712		QEL 0000 3712		0 3712	
EDGE BLENDING-START-RIGHT	min. max.		VER: 0000 VER: 3712		QER 0000 3712		0 3712	

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		FRQ50 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK	FRQ50	
		* PARAMETER3	60Hz 50Hz 48Hz 30Hz 25Hz 24Hz				ESLS1=*****: *: 6000 ESLS1=*****: *: 5000 ESLS1=*****: *: 4800 ESLS1=*****: *: 3000 ESLS1=*****: *: 2500 ESLS1=*****: *: 2400	✓ ✓ ✓ ✓ ✓ ✓
	SDI IN - SDI MODE(ET-MDN12G10)	* PARAMETER * PARAMETER1, 2 * PARAMETER3	SLOT1 SLOT2 INPUT OUTPUT	VXX: *****=VXX: *****=+***** VXX: SLSS1=VXX: SMOI 1=+***** VXX: SLSS2=VXX: SMOI 1=+***** VXX: *****=VXX: *****=+00000 VXX: *****=VXX: *****=+00001	QVX: *****=QVX: *****	*****=*****=+***** SLSS1=SMOI 1=+***** SLSS2=SMOI 1=+***** *****=*****=+00000 *****=*****=+00001	✓ ✓ ✓ ✓ ✓	
	INPUT GUIDE	OFF ON (SIMPLE)		OID: 0 OID: 1	QDI	0 1	✓ ✓	
	OSD POSITION	UPPER LEFT CETRE LEFT LOWER LEFT TOP CENTER CENTER LOEER CENTER UPPER RIGHT CENTER RIGHT LOWER RIGHT		ODP: 1 ODP: 2 ODP: 3 ODP: 4 ODP: 5 ODP: 6 ODP: 7 ODP: 8 ODP: 9	QDP	1 2 3 4 5 6 7 8 9	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓	
	OSD ROTATION	OFF CLOCKWISE COUNTER CLOCKWISE		VXX: OSRI 1=+00000 VXX: OSRI 1=+00001 VXX: OSRI 1=+00002	QVX: OSRI 1	OSRI 1=+00000 OSRI 1=+00001 OSRI 1=+00002	✓ ✓ ✓	
	OSD MEMORY	OFF ON		VXX: OMYI 0=+00000 VXX: OMYI 0=+00001	QVX: OMYI 0	OMYI 0=+00000 OMYI 0=+00001	✓ ✓	
	ON SCREEN	OFF ON		OOS: 0 OOS: 1	QOS	0 1	✓ ✓	
	WARNING MESSAGE	OFF ON		VXX: WMDI 0=+00000 VXX: WMDI 0=+00001	QVX: WMDI 0	WMDI 0=+00000 WMDI 0=+00001	✓ ✓	
	OSD DESIGN	1(YELLOW) 2(BLUE) 3(WHITE) 4(GREEN) 5(PEACH) 6(BROWN)		MOD: 0 MOD: 1 MOD: 2 MOD: 3 MOD: 4 MOD: 5	QOD	0 1 2 3 4 5	✓ ✓ ✓ ✓ ✓ ✓	
	MENU MODE	NORMAL SIMPLE		VXX: MMDI 1=+00000 VXX: MMDI 1=+00001	QVX: MMDI 1	MMDI 1=+00000 MMDI 1=+00001	✓ ✓	
	SCREEN SETTING	16:10 16:9 4:3 17:9		VSF: 0 VSF: 1 VSF: 2 VSF: 3	QSF	0 1 2 3	✓ ✓ ✓ ✓	
	SCREEN POSITION-VERTICAL	min. max.		VXX: VSPI 0=- 00120 VXX: VSPI 0=+00120	QVX: VSPI 0	VSPI 0=- 00120 VSPI 0=+00120	-120 120	
	SCREEN POSITION-HORORIZONTAL	min. max.		VXX: HSPI 0=- 00320 VXX: HSPI 0=+00320	QVX: HSPI 0	HSPI 0=- 00320 HSPI 0=+00320	-320 320	
	STARTUP LOGO	OFF USER LOGO DEFAULT LOGO		MLO: 0 MLO: 1 MLO: 2	QLO	0 1 2	✓ ✓ ✓	
	SHUTTER SETTING-FADE IN	0.0s(OFF) 0.5s 1.0s 1.5s 2.0s 2.5s 3.0s 3.5s 4.0s 5.0s 7.0s 10.0s		VXX: SEFS1=0. 0 VXX: SEFS1=0. 5 VXX: SEFS1=1. 0 VXX: SEFS1=1. 5 VXX: SEFS1=2. 0 VXX: SEFS1=2. 5 VXX: SEFS1=3. 0 VXX: SEFS1=3. 5 VXX: SEFS1=4. 0 VXX: SEFS1=5. 0 VXX: SEFS1=7. 0 VXX: SEFS1=10. 0	QVX: SEFS1	SEFS1=0. 0 SEFS1=0. 5 SEFS1=1. 0 SEFS1=1. 5 SEFS1=2. 0 SEFS1=2. 5 SEFS1=3. 0 SEFS1=3. 5 SEFS1=4. 0 SEFS1=5. 0 SEFS1=7. 0 SEFS1=10. 0	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓	
	SHUTTER SETTING-FADE OUT	0.0s(OFF) 0.5s 1.0s 1.5s 2.0s 2.5s 3.0s 3.5s 4.0s 5.0s 7.0s 10.0s		VXX: SEFS2=0. 0 VXX: SEFS2=0. 5 VXX: SEFS2=1. 0 VXX: SEFS2=1. 5 VXX: SEFS2=2. 0 VXX: SEFS2=2. 5 VXX: SEFS2=3. 0 VXX: SEFS2=3. 5 VXX: SEFS2=4. 0 VXX: SEFS2=5. 0 VXX: SEFS2=7. 0 VXX: SEFS2=10. 0	QVX: SEFS2	SEFS2=0. 0 SEFS2=0. 5 SEFS2=1. 0 SEFS2=1. 5 SEFS2=2. 0 SEFS2=2. 5 SEFS2=3. 0 SEFS2=3. 5 SEFS2=4. 0 SEFS2=5. 0 SEFS2=7. 0 SEFS2=10. 0	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓	
	SHUTTER SETTING-STARTUP	OPEN CLOSE		VXX: SEFI 3=+00000 VXX: SEFI 3=+00001	QVX: SEFI 3	SEFI 3=+00000 SEFI 3=+00001	✓ ✓	
	BACK COLOR	BLUE BLACK USER LOGO DEFAULT LOGO		OBC: 0 OBC: 1 OBC: 2 OBC: 3	QBC	0 1 2 3	✓ ✓ ✓ ✓	
	WAVEFORM MONITOR	OFF LUMINANCE RED GREEN BLUE		OWM: 0 OWM: 5 OWM: 6 OWM: 7 OWM: 8	QWM	0 5 6 7 8	✓ ✓ ✓ ✓ ✓	
	WAVEFORM MONITOR-LINE ADJ.	0 +2159		VXX: WMLI 0=+00000 VXX: WMLI 0=+02159	QVX: WMLI 0	WMLI 0=+00000 WMLI 0=+02159	✓ ✓	
	AC VOLTAGE				QVX: VMDI 2	VMDI 2=+00000 VMDI 2=+99999	✓ ✓	
	CUT OFF-RED	OFF ON		VXX: CUTI 1=+00000 VXX: CUTI 1=+00001	QVX: CUTI 1	CUTI 1=+00000 CUTI 1=+00001	✓ ✓	
	CUT OFF-GREEN	OFF ON		VXX: CUTI 2=+00000 VXX: CUTI 2=+00001	QVX: CUTI 2	CUTI 2=+00000 CUTI 2=+00001	✓ ✓	
	CUT OFF-BLUE	OFF ON		VXX: CUTI 3=+00000 VXX: CUTI 3=+00001	QVX: CUTI 3	CUTI 3=+00000 CUTI 3=+00001	✓ ✓	
	PROJECTOR ID	0(ALL) 64		RIS: 00 RIS: 64			✓ ✓	
	ID ALL	OFF ON		RVS: 0 RVS: 1	QVY	0 1	✓ ✓	
	PROJECTION METHOD INSTALLATION	FRONT/DESK REAR/DESK FRONT/CEILING REAR/CEILING FRONT/AUTO REAR/AUTO		OIL: 0 OIL: 1 OIL: 2 OIL: 3 OIL: 4 OIL: 5	QSP	0 1 2 3 4 5	✓ ✓ ✓ ✓ ✓ ✓	
	PROJECTION METHOD(AUTO)	FRONT/DESK REAR/DESK FRONT/CEILING REAR/CEILING			QVX: PJMI 2	PJMI 2=+00000 PJMI 2=+00001 PJMI 2=+00002 PJMI 2=+00003	✓ ✓ ✓ ✓	
	AUTO COOLING CONDITION-STATUS	FLOOR CEILING VERTICAL UP VERTICAL DOWN			QVX: ADRI 1	ADRI 1=+00000 ADRI 1=+00001 ADRI 1=+00002 ADRI 1=+00003	✓ ✓ ✓ ✓	
	OPERATING MODE	NORMAL ECO USER1(USER) USER2 USER3		VXX: OPEI 1=+00000 VXX: OPEI 1=+00001 VXX: OPEI 1=+00101 VXX: OPEI 1=+00102 VXX: OPEI 1=+00103	QVX: OPEI 1	OPEI 1=+00000 OPEI 1=+00001 OPEI 1=+00101 OPEI 1=+00102 OPEI 1=+00103	✓ ✓ ✓ ✓ ✓	

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL	QUERY		FRQ50 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK	FRQ50
TEST PATTERN		Color Bar V		OTS: 08		08	✓
		Convergence		OTS: 11		11	✓
		Color Bar Side		OTS: 51		51	✓
		16:9/4:3		OTS: 59		59	✓
		Focus Red		OTS: 70		70	✓
		Focus Green		OTS: 71		71	✓
		Focus Blue		OTS: 72		72	✓
		Focus Cyan		OTS: 73		73	✓
		Focus Magenta		OTS: 74		74	✓
	Focus Yellow		OTS: 75		75	✓	
	Focus		OTS: 78		78	✓	
SIGNAL LIST	SIGNAL LIST-REGISTRATION			OEM			✓
	SIGNAL LIST-DELETE	A1		ODM A1			✓
		A2		ODM A2			✓
		A7		ODM A7			✓
		A8		ODM A8			✓
		L1		ODM L1			✓
		L2		ODM L2			✓
		L7		ODM L7			✓
		L8		ODM L8			✓
	SUB MEMORY LIST-CHANGEOVER	01		OCS: 01			✓
		96		OCS: 96			✓
	SUB MEMORY LIST-CHANGEOVER (EXTENDED)	01		OCS: 01- 01			✓
96			OCS: 95- 96			✓	
SUB MEMORY LIST-REGISTRATION			OES			✓	
SUB MEMORY LIST-DELETE	01		ODS: 01- 01			✓	
	96		ODS: 95- 96			✓	
SUB MEMORY USAGE STATE	01			QSB	01	✓	
	96				96	✓	
SECURITY	SECURITY SETTING	OFF			QVX: SPWI 1	SPWI 1=+00000	✓
		ON				SPWI 1=+00001	✓
	CONTROL DEVICE SETUP-CONTROL PANEL	DISABLE		VXX: CDSI 1=+00000	QVX: CDSI 1	CDSI 1=+00000	✓
		ENABLE		VXX: CDSI 1=+00001		CDSI 1=+00001	✓
	CONTROL DEVICE SETUP-REMOTE CONTROL	USER		VXX: CDSI 1=+00002		CDSI 1=+00002	✓
		DISABLE		VXX: CDSI 2=+00000	QVX: CDSI 2	CDSI 2=+00000	✓
	ENABLE		VXX: CDSI 2=+00001		CDSI 2=+00001	✓	
	USER		VXX: CDSI 2=+00002		CDSI 2=+00002	✓	
NETWORK	WIRELESS LAN	OFF(DISABLE)		ONS: 0	QVX: WLSI 1	WLSI 1=+00000	✓
		ON(ENABLE)		ONS: 14		WLSI 1=+00014	✓
	DIGITAL LINK MODE	AUTO		VXX: DKMI 1=+00001	QVX: DKMI 1	DKMI 1=+00001	✓
		DIGITAL LINK		VXX: DKMI 1=+00002		DKMI 1=+00002	✓
		ETHERNET		VXX: DKMI 1=+00003		DKMI 1=+00003	✓
		LONG REACH MODE		VXX: DKMI 1=+00004		DKMI 1=+00004	✓
	DIGITAL LINK STATUS-LINK	NO LINK			QVX: DKSI 1	DKSI 1=+00000	✓
		DIGITAL LINK				DKSI 1=+00001	✓
		LPM				DKSI 1=+00002	✓
		ETHERNET				DKSI 1=+00003	✓
	DIGITAL LINK STATUS-HDCP STATUS	NO SIGNAL			QVX: DKSI 2	DKSI 2=+00000	✓
		OFF				DKSI 2=+00001	✓
		ON				DKSI 2=+00002	✓
	DIGITAL LINK STATUS-SIGNAL QUALITY (MIN)	-255			QVX: DKSI 3	DKSI 3=- 00255	✓
		0				DKSI 3=+00000	✓
	DIGITAL LINK STATUS-SIGNAL QUALITY (MAX)	-255			QVX: DKSI 4	DKSI 4=- 00255	✓
		0				DKSI 4=+00000	✓
	DIGITAL LINK INPUT CH LIST	HD1:HDMI1,HD2:HDMI2...			QVX: DLIS1	DLIS1=HD1: HDMI 1, ***, **	✓
	PROJECTOR NAME SETTING	PROJECTOR1		VXX: NCGS8=PROJECTOR1	QVX: NCGS8	NCGS8=PROJECTOR1	✓
	Art-Net SETUP	OFF		VXX: DANI 1=+00000	QVX: DANI 1	DANI 1=+00000	✓
ON(2.*.*)			VXX: DANI 1=+00002		DANI 1=+00002	✓	
ON(10.*.*)			VXX: DANI 1=+00003		DANI 1=+00003	✓	
ON(MANUAL)			VXX: DANI 1=+00004		DANI 1=+00004	✓	
Art-Net SETUP-START ADDRESS	1		VXX: DANI 3=+00001	QVX: DANI 3	DANI 3=+00001	✓	
	501		VXX: DANI 3=+00501		DANI 3=+00501	✓	
Art-Net SETUP-NET	0		VXX: DANI 4=+00000	QVX: DANI 4	DANI 4=+00000	✓	
	127		VXX: DANI 4=+00127		DANI 4=+00127	✓	
Art-Net SETUP-SUB NET	0		VXX: DANI 5=+00000	QVX: DANI 5	DANI 5=+00000	✓	
	15		VXX: DANI 5=+00015		DANI 5=+00015	✓	
Art-Net SETUP-UNIVERS	0		VXX: DANI 6=+00000	QVX: DANI 6	DANI 6=+00000	✓	
	15		VXX: DANI 6=+00015		DANI 6=+00015	✓	
Art-Net SETUP-CHANNEL SETTING	DEFAULT		VXX: DANI 8=+00000	QVX: DANI 8	DANI 8=+00000	✓	
	1		VXX: DANI 8=+00001		DANI 8=+00001	✓	
	2		VXX: DANI 8=+00002		DANI 8=+00002	✓	
	USER		VXX: DANI 8=+00100		DANI 8=+00100	✓	
PRESHOW MODE	OFF			QVX: PSMI 1	PSMI 1=+00000	✓	
	ON				PSMI 1=+00001	✓	

Note: The commands or parameters with "*" shows available commands or parameters for the projector which has been activated by the Upgrade Kit.