

Control Commands

Model No. PT-MZ880
PT-MZ780
PT-MZ680
PT-SMZ58C



- Please refer to the Operating Instructions for the serial command format, limitations, connection and other details.
- シリアルコマンドのフォーマット、制限事項、接続方法およびその他詳細につきましては、各モデルの取扱説明書をご覧ください。
- 有关串行控制命令的格式、限制事项、连接方法以及其他详情、请参阅各机型的使用说明书。

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK	MZ880 MZ780 MZ680 SMZ58C	
BASIC OPERATION REMOTE CONTROL	POWER	ON		PON	QPW	001		✓
		OFF (STANDBY)		POF		000		✓
	VOLUME	UP		AUU				✓
		DOWN		AUD				✓
	INPUT SELECT	COMPUTER1		IIS:RG1	QIN	RG1		✓
		COMPUTER2		IIS:RG2		RG2		✓
		HDMI1		IIS:HD1		HD1		✓
		HDMI3		IIS:HD3		HD3		✓
		DIGITAL LINK		IIS:DL1		DL1		✓
	INPUT SELECT (DIGITAL LINK)	COMPUTER1		IIS:DL1:PC1	QIN	DL1:PC1		✓
		HDMI1		IIS:DL1:HD1		DL1:HD1		✓
		HDMI2		IIS:DL1:HD2		DL1:HD2		✓
	FREEZE	OFF		OFZ:0	QFZ	0		✓
		ON		OFZ:1		1		✓
	MENU KEY			OMN				✓
	RETURN KEY			OBK				✓
	ENTER KEY			OEN				✓
	UP KEY			OCU				✓
	DOWN KEY			OCD				✓
	LEFT KEY			OCL				✓
	RIGHT KEY			OCR				✓
	DEFAULT KEY			OST				✓
	AUTO SETUP KEY			OAS				✓
	SHUTTER	OFF		OSH:0	QSH	0		✓
		ON		OSH:1		1		✓
	SHUTTER(Toggle)	OFF		OSH	QSH	0		✓
		ON				1		✓
	DIGITAL ZOOM UP			DZU				✓
	DIGITAL ZOOM DOWN			DZD				✓
	FUNCTION KEY			FC1				✓
	SYSTEM SELCTOR KEY			OSL				✓
	ASPECT KEY			VS1				✓
	ECO			OEC				✓
	NUMERIC KEY	0		ONK:0				✓
		1		ONK:1				✓
		2		ONK:2				✓
		3		ONK:3				✓
		4		ONK:4				✓
		5		ONK:5				✓
		6		ONK:6				✓
		7		ONK:7				✓
		8		ONK:8				✓
		9		ONK:9				✓
	LENS HOME POSITION	EXECUTE		VXX:LNSI1=+00001				✓
	LENS SHIFT-HORIZONTAL	SLOW+		VXX:LNSI2=+00000				✓
	SLOW-		VXX:LNSI2=+00001				✓	
	NORMAL+		VXX:LNSI2=+00100				✓	
	NORMAL-		VXX:LNSI2=+00101				✓	
	FAST+		VXX:LNSI2=+00200				✓	
	FAST-		VXX:LNSI2=+00201				✓	
LENS SHIFT-VERTICAL	SLOW+		VXX:LNSI3=+00000				✓	
	SLOW-		VXX:LNSI3=+00001				✓	
	NORMAL+		VXX:LNSI3=+00100				✓	
	NORMAL-		VXX:LNSI3=+00101				✓	
	FAST+		VXX:LNSI3=+00200				✓	
	FAST-		VXX:LNSI3=+00201				✓	
LENS FOCUS	SLOW+		VXX:LNSI4=+00000				✓	
	SLOW-		VXX:LNSI4=+00001				✓	
	NORMAL+		VXX:LNSI4=+00100				✓	
	NORMAL-		VXX:LNSI4=+00101				✓	
	FAST+		VXX:LNSI4=+00200				✓	
	FAST-		VXX:LNSI4=+00201				✓	
LENS ZOOM	SLOW+		VXX:LNSI5=+00000				✓	
	SLOW-		VXX:LNSI5=+00001				✓	
	NORMAL+		VXX:LNSI5=+00100				✓	
	NORMAL-		VXX:LNSI5=+00101				✓	
	FAST+		VXX:LNSI5=+00200				✓	
	FAST-		VXX:LNSI5=+00201				✓	
STATUS KEY			STS				✓	
LENS FOCUS KEY			OLF				✓	
LENS SHIFT KEY			OLH				✓	
LENS ZOOM KEY			OLZ				✓	
DIGITAL LINK KEY			DLK				✓	
INPUT MENU KEY			IPT				✓	
P-TIMER			PTM				✓	
SCREEN ADJUSTMENT			OSA				✓	
AUDIO MUTE	OFF		AMT:0	QMT	0		✓	
	ON		AMT:1		1		✓	
SELF DIAGNOSIS				QVX:ERRS1	ERRS1=*****		✓	
PICTURE MODE	DYNAMIC		VPM:DYN	QPM	DYN		✓	
	NATURAL		VPM:NAT		NAT		✓	
	STANDARD		VPM:STD		STD		✓	
	WHITE BOARD		VPM:WBD		WBD		✓	
	CINEMA		VPM:CIN		CIN		✓	
	DICOM SIM.		VPM:DIC		DIC		✓	
CONTRAST	+1		VCN:001	QVR	001		✓	
	+63		VCN:063		063		✓	
BRIGHTNESS	+1		VBR:001	QVB	001		✓	
	+63		VBR:063		063		✓	
COLOR	+1		VCO:001	QVC	001		✓	
	+63		VCO:063		063		✓	
TINT	+1		VTN:001	QVT	001		✓	
	+63		VTN:063		063		✓	
SHARPNESS	0		VSR:000	QVS	000		✓	
	15		VSR:015		015		✓	
COLOR TEMPERATURE	LOW		OTE:0	QTE	0		✓	
	HIGH		OTE:2		2		✓	
	USER		OTE:4		4		✓	
	USER1(USER)		OTE:04		4		✓	
	DEFAULT		OTE:10		10		✓	
COLOR TEMP-NAME SETTING USER1	COLORTEMP1		VXX:NCGS1=COLORTEMP1	QVX:NCGS1	NCGS1=COLORTEMP1		✓	
COLOR TEMP-NAME SETTING USER2	COLORTEMP2		VXX:NCGS3=COLORTEMP2	QVX:NCGS3	NCGS3=COLORTEMP2		✓	
COLOR TEMP-NAME CLEAR USER1	COLORTEMP1		VXX:NCLI1=+00000				✓	
COLOR TEMP-NAME CLEAR USER2	COLORTEMP2		VXX:NCLI3=+00000				✓	
WHITE BALANCE LOW-RED	-127		VOR:001	QOR	001		✓	
	+127		VOR:255		255		✓	
WHITE BALANCE LOW-GREEN	-127		VOG:001	QOG	001		✓	
	+127		VOG:255		255		✓	
WHITE BALANCE LOW-BLUE	-127		VOB:001	QOB	001		✓	
	+127		VOB:255		255		✓	
WHITE BALANCE HIGH-RED	0		VHR:000	QHR	000		✓	
	+255		VHR:255		255		✓	
WHITE BALANCE HIGH-GREEN	0		VHG:000	QHG	000		✓	
	+255		VHG:255		255		✓	
WHITE BALANCE HIGH-BLUE	0		VHB:000	QHB	000		✓	
	+255		VHB:255		255		✓	
GAMMA(PRESET)	-8		VXX:GAMI1=-00008	QVX:GAMI1	GAMI1=-00008		✓	
	+7		VXX:GAMI1=+00007		GAMI1=+00007		✓	

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK		
	DAYLIGHT VIEW	OFF		VXX:DLVI0=+00000	QVX:DLVI0	DLVI0=+00000		✓
		AUTO		VXX:DLVI0=+00001		DLVI0=+00001		✓
		1		VXX:DLVI0=+00002		DLVI0=+00002		✓
		2		VXX:DLVI0=+00003		DLVI0=+00003		✓
		3		VXX:DLVI0=+00004		DLVI0=+00004		✓
	NOISE REDUCTION	OFF		VNS:0	QNS	0		✓
		1		VNS:1		1		✓
		2		VNS:2		2		✓
		3		VNS:3		3		✓
	DYNAMIC CONTRAST/IRIS	OFF		OAI:0	QAI	0		✓
		1		OAI:1		1		✓
		2		OAI:2		2		✓
		USER		OAI:4		4		✓
	DYNAMIC CONTRAST (LIGHTS OUT TIMER)	DISABLE		VXX:DYCS2=OFF	QVX:DYCS2	OFF		✓
		0.0s		VXX:DYCS2=0.0		0.0		✓
	10.0s		VXX:DYCS2=10.0		10.0		✓	
DYNAMIC CONTRAST (LIGHTS OUT SIGNAL LEVEL)	0		VXX:DYCI3=+00000	QVX:DYCI3	00000		✓	
	5		VXX:DYCI3=+00005		00005		✓	
TV-SYSTEM	AUTO1		VSG:AT1	QSG	AT1		✓	
	AUTO2		VSG:AT2		AT2		✓	
	NTSC		VSG:NTS		NTS		✓	
	NTSC4.43		VSG:N44		N44		✓	
	PAL		VSG:PAL		PAL		✓	
	PAL-M		VSG:PAM		PAM		✓	
	PAL-N		VSG:PAN		PAN		✓	
	PAL60		VSG:P60		P60		✓	
	SECAM		VSG:SEC		SEC		✓	
SYSTEM SELECTOR RGB(VGA/480P)	VGA60		ORF:0	QRF	0		✓	
	480P(YCbCr)		ORF:1		1		✓	
	480p(RGB)		ORF:3		3		✓	
SYSTEM SELECTOR RGB(Other)/DVI/SLOT-DVI	RGB		ORF:0	QRF	0		✓	
	YPbPr		ORF:1		1		✓	
SYSTEM SELECTOR HDMI/DIGITAL LINK/DisplayPort/SLOT-HDMI/SLOT-DIGITAL LINK/	RGB		ORF:0	QRF	0		✓	
	YPbPr		ORF:1		1		✓	
	AUTO		ORF:2		2		✓	
POSITION	REAL TIME KEYSTONE	OFF		OAK:0	QAK	0		✓
		ON		OAK:1		1		✓
	DIGITAL IMAGE SHIFT-HORIZONTAL	min.		VXX:DISI1=-00192	QVX:DISI1	DISI1=-00192		✓
		max.		VXX:DISI1=00192		DISI1=00192		✓
	DIGITAL IMAGE SHIFT-VERTICAL	min.		VXX:DISI2=-00120	QVX:DISI2	DISI2=-00120		✓
		max.		VXX:DISI2=00120		DISI2=00120		✓
	DIGITAL IMAGE SHIFT-HORIZONTAL(relative)	min.		VXX:DISI3=-00001				✓
		max.		VXX:DISI3=+00001				✓
	DIGITAL IMAGE SHIFT-VERTICAL(relative)	min.		VXX:DISI4=-00001				✓
		max.		VXX:DISI4=+00001				✓
	KEYSTONE-LENS THROW RATIO	0.9		VXX:GMKS0=0.9	QVX:GMKS0	GMKS0=00.9		✓
		1.4		VXX:GMKS0=1.4		GMKS0=01.4		✓
		2.3		VXX:GMKS0=2.3		GMKS0=02.3		✓
	CURVED CORRECTION-HORIZONTAL ARC.	-40		VXX:GMCI7=-00040	QVX:GMCI7	GMCI7=-00040		✓
		+40		VXX:GMCI7=+00040		GMCI7=+00040		✓
	CURVED CORRECTION-VERTICAL ARC	-40		VXX:GMCI3=-00040	QVX:GMCI3	GMCI3=-00040		✓
		+40		VXX:GMCI3=+00040		GMCI3=+00040		✓
	GEOMETRY	OFF		VXX:GMMI0=+00000	QVX:GMMI0	GMMI0=+00000		✓
		KEYSTONE		VXX:GMMI0=+00001		GMMI0=+00001		✓
		CURVED		VXX:GMMI0=+00002		GMMI0=+00002		✓
		PC-1		VXX:GMMI0=+00003		GMMI0=+00003		✓
		PC-2		VXX:GMMI0=+00004		GMMI0=+00004		✓
		PC-3		VXX:GMMI0=+00005		GMMI0=+00005		✓
		CORNER-CORRECTION		VXX:GMMI0=+00010		GMMI0=+00010		✓
	GEOMETRY-KEYSTONE-LENS THROW RATIO	0.7	0.1 step	VXX:GMKS0=+00.7	QVX:GMKS0	GMKS0=+00.7	+00.5	✓
		16.5		VXX:GMKS0=+16.5		GMKS0=+16.5	+10.5	✓
	GEOMETRY-KEYSTONE-VERTICAL BALANCE	-60		VXX:GMKI4=-00060	QVX:GMKI4	GMKI4=-00060		✓
		+60		VXX:GMKI4=+00060		GMKI4=+00060		✓
	GEOMETRY-KEYSTONE-HORIZONTAL BALANCE	-30		VXX:GMKI7=-00030	QVX:GMKI7	GMKI7=-00030		✓
		+30		VXX:GMKI7=+00030		GMKI7=+00030		✓
	GEOMETRY-KEYSTONE-VERTICAL KEYSTONE	-40.0 (-45.0)*	0.2 step	VXX:GMKS8=-40.0	QVX:GMKS8	GMKS8=-40.0	-25.0(0.5step)	✓
		+40.0 (+45.0)*		VXX:GMKS8=+40.0		GMKS8=+40.0	+25.0(0.5step)	✓
	GEOMETRY-KEYSTONE-HORIZONTAL KEYSTONE	-15.0 (-40.0)*	0.2 step	VXX:GMKS9=-15.0	QVX:GMKS9	GMKS9=-15.0	-30.0(0.5step)	✓
		+15.0 (+40.0)*		VXX:GMKS9=+15.0		GMKS9=+15.0	+30.0(0.5step)	✓
	GEOMETRY-CURVED-LENS THROW RATIO	0.7	0.1 step	VXX:GMCS0=+00.7	QVX:GMCS0	GMCS0=+00.7	+00.5	✓
		16.5		VXX:GMCS0=+16.5		GMCS0=+16.5	+10.5	✓
	GEOMETRY-CURVED-VERTICAL ARC	-50 (-100)*		VXX:GMCI3=-00050	QVX:GMCI3	GMCI3=-00050		✓
		+50 (+100)*		VXX:GMCI3=+00050		GMCI3=+00050		✓
	GEOMETRY-CURVED-HORIZONTAL ARC	-50 (-100)*		VXX:GMCI7=-00050	QVX:GMCI7	GMCI7=-00050		✓
		+50 (+100)*		VXX:GMCI7=+00050		GMCI7=+00050		✓
	GEOMETRY-CURVED-VERTICAL BALANCE	-60		VXX:GMCI2=-00060	QVX:GMCI2	GMCI2=-00060		✓
		+60		VXX:GMCI2=+00060		GMCI2=+00060		✓
	GEOMETRY-CURVED-HORIZONTAL BALANCE	-30		VXX:GMCI6=-00030	QVX:GMCI6	GMCI6=-00030		✓
		+30		VXX:GMCI6=+00030		GMCI6=+00030		✓
	GEOMETRY-CURVED-VERTICAL KEYSTONE	-40.0 (-45.0)*	0.2 step	VXX:GMCS8=-40.0	QVX:GMCS8	GMCS8=-40.0	-25.0(0.5step)	✓
	+40.0 (+45.0)*		VXX:GMCS8=+40.0		GMCS8=+40.0	+25.0(0.5step)	✓	
GEOMETRY-CURVED-HORIZONTAL KEYSTONE	-15.0 (-40.0)*	0.2 step	VXX:GMCS9=-15.0	QVX:GMCS9	GMCS9=-15.0	-30.0(0.5step)	✓	
	+15.0 (+40.0)*		VXX:GMCS9=+15.0		GMCS9=+15.0	+30.0(0.5step)	✓	
GEOMETRY-CURVED-MAINTAIN ASPECT RATIO	OFF		VXX:GMCI7=+00000	QVX:GMCI7	GMCI7=+00000		✓	
	ON		VXX:GMCI7=+00001		GMCI7=+00001		✓	
GEOMETRY-CORNER CORRECTION-UPPER LEFT(V)	min.		VXX:GMFI1=+00000	QVX:GMFI1	GMFI1=+00000	0	✓	
	max.		VXX:GMFI1=+00300		GMFI1=+00300	+300	✓	
GEOMETRY-CORNER CORRECTION-UPPER RIGHT(V)	min.		VXX:GMFI2=+00000	QVX:GMFI2	GMFI2=+00000	0	✓	
	max.		VXX:GMFI2=+00300		GMFI2=+00300	+300	✓	
GEOMETRY-CORNER CORRECTION-LOWER LEFT(V)	min.		VXX:GMFI3=-00300	QVX:GMFI3	GMFI3=-00300	-300	✓	
	max.		VXX:GMFI3=+00000		GMFI3=+00000	0	✓	
GEOMETRY-CORNER CORRECTION-LOWER RIGHT(V)	min.		VXX:GMFI4=-00300	QVX:GMFI4	GMFI4=-00300	-300	✓	
	max.		VXX:GMFI4=+00000		GMFI4=+00000	0	✓	
GEOMETRY-CORNER CORRECTION-LINEARITY(V)	min.		VXX:GMFI5=-00127	QVX:GMFI5	GMFI5=-00127	-127	✓	
	max.		VXX:GMFI5=+00127		GMFI5=+00127	+127	✓	
GEOMETRY-CORNER CORRECTION-UPPER LEFT(H)	min.		VXX:GMFI6=+00000	QVX:GMFI6	GMFI6=+00000	0	✓	
	max.		VXX:GMFI6=+00480		GMFI6=+00480	+480	✓	
GEOMETRY-CORNER CORRECTION-UPPER RIGHT(H)	min.		VXX:GMFI7=-00480	QVX:GMFI7	GMFI7=-00480	-480	✓	
	max.		VXX:GMFI7=+00000		GMFI7=+00000	0	✓	
GEOMETRY-CORNER CORRECTION-LOWER LEFT(H)	min.		VXX:GMFI8=+00000	QVX:GMFI8	GMFI8=+00000	0	✓	
	max.		VXX:GMFI8=+00480		GMFI8=+00480	+480	✓	
GEOMETRY-CORNER CORRECTION-LOWER RIGHT(H)	min.		VXX:GMFI9=-00480	QVX:GMFI9	GMFI9=-00480	-480	✓	
	max.		VXX:GMFI9=+00000		GMFI9=+00000	0	✓	
GEOMETRY-CORNER CORRECTION-LINEARITY(H)	min.		VXX:GMFIA=-00127	QVX:GMFIA	GMFIA=-00127	-127	✓	
	max.		VXX:GMFIA=+00127		GMFIA=+00127	+127	✓	
GEOMETRY-CORNER/PINCUSHION-LINEARITY	AUTO		VXX:GMFIF=+00000	QVX:GMFIF	GMFIF=+00000		✓	
	MANUAL		VXX:GMFIF=+00001		GMFIF=+00001		✓	
SHIFT-HORIZONTAL	0		VTH:0000	QTH	0000		✓	
	+4095		VTH:4095		4095		✓	
SHIFT-VERTICAL	0		VTV:0000	QTV	0000		✓	
	+4094		VTV:4094		4094		✓	
CLOCK PHASE	0		VCP:000	QCP	000		✓	
	+31		VCP:031		063		✓	
ASPECT	AUTO/VID AUTO/DEFAULT		VSE:0	QSE	0		✓	
	NORMAL(4:3)		VSE:1		1		✓	
	WIDE(16:9)		VSE:2		2		✓	
	NATIVE(through)		VSE:5		5		✓	

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK		
		FULL(HV FIT)		VSE: 6		6		✓
		H-FIT		VSE: 9		9		✓
		V-FIT		VSE: 10		10		✓
	ZOOM-HORIZONTAL	50		OZH: 050	QZH	050		✓
		999		OZH: 999		999		✓
	ZOOM-VERTICAL	50		OZV: 050	QZV	050		✓
		999		OZV: 999		999		✓
	ZOOM-BOTH	50		OZO: 050	QZO	050		✓
	999		OZO: 999		999		✓	
ZOOM-INTERLOCKED	OFF		OZS: 0	QZS	0		✓	
	ON		OZS: 1		1		✓	
ZOOM-MODE	INTERNAL		OZT: 0	QZT	0		✓	
	FULL		OZT: 1		1		✓	
FRAME LOCK	OFF		VFL: 0	QFL	0		✓	
	ON		VFL: 1		1		✓	
ADVANCED	DIGITAL CINEMA REALITY	AUTO		OPD: 0	QPD	0		✓
		OFF		OPD: 1		1		✓
		30p/25p FIXED		OPD: 2		2		✓
	BLANKING-UPPER	min.		DBU: 000	QLU	000		0
		max.		DBU: 2398		2398		599
	BLANKING-LOWER	min.		DBB: 000	QLB	000		0
		max.		DBB: 2398		2398		599
	BLANKING-RIGHT	min.		DBR: 000	QLR	000		0
		max.		DBR: 3838		3838		959
	BLANKING-LEFT	min.		DBL: 000	QLL	000		0
		max.		DBL: 3838		3838		959
	INPUT RESOLUTION-TOTAL DOTS	330		VTD: 0330	QTD	0330		✓
		4095		VTD: 4095		4095		✓
	INPUT RESOLUTION-DISPLAY DOTS	300		VDD: 0300	QDD	0300		✓
		4065		VDD: 4065		4065		✓
	INPUT RESOLUTION-TOTAL LINES	155		VTL: 0155	QTL	0155		✓
		2047		VTL: 2047		2047		✓
	INPUT RESOLUTION-DISPLAY LINES	150		VDL: 0150	QDL	0150		✓
		2037		VDL: 2037		2037		✓
	CLAMP POSITION	1		VLT: 001	QLT	001		✓
		255		VLT: 255		255		✓
	EDGE BLENDING	OFF		VXX: EDBI0=+00000	QVX: EDBI0	EDBI0=+00000		✓
		ON		VXX: EDBI0=+00001		EDBI0=+00001		✓
	EDGE BLENDING-UPPER ON/OFF	OFF		VGU: 0	QGU	0		✓
		ON		VGU: 1		1		✓
	EDGE BLENDING-LOWER ON/OFF	OFF		VGB: 0	QGB	0		✓
		ON		VGB: 1		1		✓
	EDGE BLENDING-LEFT ON/OFF	OFF		VGL: 0	QGL	0		✓
		ON		VGL: 1		1		✓
	EDGE BLENDING-RIGHT ON/OFF	OFF		VGR: 0	QGR	0		✓
		ON		VGR: 1		1		✓
	EDGE BLENDING-START-UPPER	min.		VEU: 0000	QEU	0000		✓
		max.		VEU: 2272		2272		1200
	EDGE BLENDING-START-LOWER	min.		VEB: 0000	QEB	0000		✓
		max.		VEB: 2272		2272		1200
	EDGE BLENDING-START-LEFT	min.		VEL: 0000	QEL	0000		✓
		max.		VEL: 3712		3712		1920
	EDGE BLENDING-START-RIGHT	min.		VER: 0000	QER	0000		✓
		max.		VER: 3712		3712		1920
	EDGE BLENDING-WIDTH-UPPER	min.		VXX: EUWI0=+00000	QVX: EUWI0	EUWI0=+00000		✓
		max.		VXX: EUWI0=+02272		EUWI0=+02272		1200
	EDGE BLENDING-WIDTH-LOWER	min.		VXX: EBWI0=+00000	QVX: EBWI0	EBWI0=+00000		✓
	max.		VXX: EBWI0=+02272		EBWI0=+02272		1200	
EDGE BLENDING-WIDTH-LEFT	min.		VXX: ELWI0=+00000	QVX: ELWI0	ELWI0=+00000		✓	
	max.		VXX: ELWI0=+03712		ELWI0=+03712		1920	
EDGE BLENDING-WIDTH-RIGHT	min.		VXX: ERWI0=+00000	QVX: ERWI0	ERWI0=+00000		✓	
	max.		VXX: ERWI0=+03712		ERWI0=+03712		1920	
EDGE BLENDING-MARKER-ON/OFF	OFF		VGM: 0	QGM	0		✓	
	ON		VGM: 1		1		✓	
EDGE BLENDING-NON-OVERLAPPED BLACK LEVEL	0 (W,R,G,B)		VJI: 000,000,000,000	QJI	000,000,000,000		✓	
	255 (W,R,G,B)		VJI: 255,255,255,255		255,255,255,255		✓	
EDGE BLENDING-NON-OVERLAPPED BLACK LEVEL-INTERLOCKED	OFF		VXX: EBII1=+00000	QVX: EBII1	EBII1=+00000		✓	
	ON		VXX: EBII1=+00001		EBII1=+00001		✓	
EDGE BLENDING-BLACK BORDER LEVEL	0 (W,R,G,B)		VJO: 000,000,000,000	QJO	000,000,000,000		✓	
	255 (W,R,G,B)		VJO: 255,255,255,255		255,255,255,255		✓	
EDGE BLENDING-BLACK BORDER LEVEL-INTERLOCKED	OFF		VXX: EBII2=+00000	QVX: EBII2	EBII2=+00000		✓	
	ON		VXX: EBII2=+00001		EBII2=+00001		✓	
EDGE BLENDING-BLACK BORDER WIDTH-UPPER	min.		VJU: 0000	QJU	0000		✓	
	max.		VJU: 2272		2272		1200	
EDGE BLENDING-BLACK BORDER WIDTH-LOWER	min.		VJB: 0000	QJB	0000		✓	
	max.		VJB: 2272		2272		1200	
EDGE BLENDING-BLACK BORDER WIDTH-LEFT	min.		VJL: 0000	QJL	0000		✓	
	max.		VJL: 3712		3712		1920	
EDGE BLENDING-BLACK BORDER WIDTH-RIGHT	min.		VJR: 0000	QJR	0000		✓	
	max.		VJR: 3712		3712		1920	
EDGE BLENDING-BLACK BORDER WIDTH-UPPER KEYSTONE AREA	min.		VXX: EBBI4=-02272	QVX: EBBI4	EBBI4=-02272		-1200	
	max.		VXX: EBBI4=+02272		EBBI4=+02272		1200	
EDGE BLENDING-BLACK BORDER WIDTH-LOWER KEYSTONE AREA	min.		VXX: EBBI5=-02272	QVX: EBBI5	EBBI5=-02272		-1200	
	max.		VXX: EBBI5=+02272		EBBI5=+02272		1200	
EDGE BLENDING-BLACK BORDER WIDTH-LEFT KEYSTONE AREA	min.		VXX: EBBI6=-03712	QVX: EBBI6	EBBI6=-03712		-1920	
	max.		VXX: EBBI6=+03712		EBBI6=+03712		1920	
EDGE BLENDING-BLACK BORDER WIDTH-RIGHT KEYSTONE AREA	min.		VXX: EBBI7=-03712	QVX: EBBI7	EBBI7=-03712		-1920	
	max.		VXX: EBBI7=+03712		EBBI7=+03712		1920	
EDGE BLENDING-OVERLAPPED BLACK LEVEL-UPPER	0 (W,R,G,B)		VXX: EBBS0=000,000,000,000	QVX: EBBS0	EBBS0=000,000,000,000		✓	
	255 (W,R,G,B)		VXX: EBBS0=255,255,255,255		EBBS0=255,255,255,255		✓	
EDGE BLENDING-OVERLAPPED BLACK LEVEL-LOWER	0 (W,R,G,B)		VXX: EBBS1=000,000,000,000	QVX: EBBS1	EBBS1=000,000,000,000		✓	
	255 (W,R,G,B)		VXX: EBBS1=255,255,255,255		EBBS1=255,255,255,255		✓	
EDGE BLENDING-OVERLAPPED BLACK LEVEL-LEFT	0 (W,R,G,B)		VXX: EBBS2=000,000,000,000	QVX: EBBS2	EBBS2=000,000,000,000		✓	
	255 (W,R,G,B)		VXX: EBBS2=255,255,255,255		EBBS2=255,255,255,255		✓	
EDGE BLENDING-OVERLAPPED BLACK LEVEL-RIGHT	0 (W,R,G,B)		VXX: EBBS3=000,000,000,000	QVX: EBBS3	EBBS3=000,000,000,000		✓	
	255 (W,R,G,B)		VXX: EBBS3=255,255,255,255		EBBS3=255,255,255,255		✓	
EDGE BLENDING-OVERLAPPED BLACK LEVEL-UPPER INTERLOCKED	OFF		VXX: EBII3=+00000	QVX: EBII3	EBII3=+00000		✓	
	ON		VXX: EBII3=+00001		EBII3=+00001		✓	
EDGE BLENDING-OVERLAPPED BLACK LEVEL-LOWER INTERLOCKED	OFF		VXX: EBII4=+00000	QVX: EBII4	EBII4=+00000		✓	
	ON		VXX: EBII4=+00001		EBII4=+00001		✓	
EDGE BLENDING-OVERLAPPED BLACK LEVEL-LEFT INTERLOCKED	OFF		VXX: EBII5=+00000	QVX: EBII5	EBII5=+00000		✓	
	ON		VXX: EBII5=+00001		EBII5=+00001		✓	
EDGE BLENDING-OVERLAPPED BLACK LEVEL-RIGHT INTERLOCKED	OFF		VXX: EBII6=+00000	QVX: EBII6	EBII6=+00000		✓	
	ON		VXX: EBII6=+00001		EBII6=+00001		✓	
EDGE BLENDING-AUTO TESTPATTERN	OFF		VXX: EATI1=+00000	QVX: EATI1	EATI1=+00000		✓	
	ON		VXX: EATI1=+00001		EATI1=+00001		✓	
RASTER POSITION-HORIZONTAL	-2048		VRH: 2952	QRH	2952		✓	
	+2047		VRH: 7047		7047		✓	
RASTER POSITION-VERTICAL	-2048		VRV: 2952	QRV	2952		✓	
	+2047		VRV: 7047		7047		✓	
	LANGUAGE	English		OLG: ENG	QLG	ENG		✓
		German		OLG: DEU		DEU		✓
		French		OLG: FRA		FRA		✓
		Spanish		OLG: ESP		ESP		✓
		Italian		OLG: ITL		ITL		✓
		Japanese		OLG: JPN		JPN		✓
		Chinese		OLG: CHI		CHI		✓
	Russian		OLG: RUS		RUS		✓	

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK		
DISPLAY LANGUAGE		Korea		OLG: KOR		KOR		✓
		Portuguse		OLG: POR		POR		✓
		Swedish		OLG: SVE		SVE		✓
		Norwegian		OLG: NOR		NOR		✓
		Danish		OLG: DAN		DAN		✓
		Polish		OLG: POL		POL		✓
		Czech		OLG: CES		CES		✓
		Hungarian		OLG: MAG		MAG		✓
		Thai		OLG: THA		THA		✓
		Dutch		OLG: NLD		NLD		✓
		Finnish		OLG: FIN		FIN		✓
		Romanian		OLG: RUM		RUM		✓
		Turkish		OLG: TUR		TUR		✓
		Arabic		OLG: ARA		ARA		✓
	Kazakh		OLG: KAZ		KAZ		✓	
	Vietnamese		OLG: VIE		VIE		✓	
	COLOR MATCHING	OFF		VXX: CMAI0=+00000	QVX: CMAI0	CMAI0=+00000		✓
		3COLORS		VXX: CMAI0=+00001		CMAI0=+00001		✓
		7COLORS		VXX: CMAI0=+00002		CMAI0=+00002		✓
	COLOR MATCHING-3COLORS-RED	0 (R,G,B)		VMR: 0000, 0000, 0000	QMR	0000, 0000, 0000		✓
		2048, 2048, 2048(R,G,B)		VMR: 2048, 2048, 2048		2048, 2048, 2048		✓
	COLOR MATCHING-3COLORS-GREEN	0 (R,G,B)		VMG: 0000, 0000, 0000	QMG	0000, 0000, 0000		✓
		2048, 2048, 2048(R,G,B)		VMG: 2048, 2048, 2048		2048, 2048, 2048		✓
	COLOR MATCHING-3COLORS-BLUE	0 (R,G,B)		VMB: 0000, 0000, 0000	QMB	0000, 0000, 0000		✓
		2048, 2048, 2048(R,G,B)		VMB: 2048, 2048, 2048		2048, 2048, 2048		✓
	COLOR MATCHING-3COLORS-WHITE	256 (GAIN)		VMW: 0256	QMW	0256		✓
		2048 (GAIN)		VMW: 2048		2048		✓
	COLOR MATCHING-3COLORS-AUTO TESTPATTERN	OFF		VXX: CATI0=+00000	QVX: CATI0	CATI0=+00000		✓
		ON		VXX: CATI0=+00001		CATI0=+00001		✓
	COLOR MATCHING-7COLORS-RED	0 (R,G,B)		VXX: C7CS0=0000, 0000, 0000	QVX: C7CS0	C7CS0=0000, 0000, 0000		✓
		2048(R,G,B)		VXX: C7CS0=2048, 2048, 2048		C7CS0=2048, 2048, 2048		✓
	COLOR MATCHING-7COLORS-GREEN	0 (R,G,B)		VXX: C7CS1=0000, 0000, 0000	QVX: C7CS1	C7CS1=0000, 0000, 0000		✓
		2048(R,G,B)		VXX: C7CS1=2048, 2048, 2048		C7CS1=2048, 2048, 2048		✓
	COLOR MATCHING-7COLORS-BLUE	0 (R,G,B)		VXX: C7CS2=0000, 0000, 0000	QVX: C7CS2	C7CS2=0000, 0000, 0000		✓
		2048(R,G,B)		VXX: C7CS2=2048, 2048, 2048		C7CS2=2048, 2048, 2048		✓
	COLOR MATCHING-7COLORS-CYAN	0 (R,G,B)		VXX: C7CS3=0000, 0000, 0000	QVX: C7CS3	C7CS3=0000, 0000, 0000		✓
		2048(R,G,B)		VXX: C7CS3=2048, 2048, 2048		C7CS3=2048, 2048, 2048		✓
	COLOR MATCHING-7COLORS-MAGENTA	0 (R,G,B)		VXX: C7CS4=0000, 0000, 0000	QVX: C7CS4	C7CS4=0000, 0000, 0000		✓
		2048(R,G,B)		VXX: C7CS4=2048, 2048, 2048		C7CS4=2048, 2048, 2048		✓
	COLOR MATCHING-7COLORS-YELLOW	0 (R,G,B)		VXX: C7CS5=0000, 0000, 0000	QVX: C7CS5	C7CS5=0000, 0000, 0000		✓
		2048(R,G,B)		VXX: C7CS5=2048, 2048, 2048		C7CS5=2048, 2048, 2048		✓
	COLOR MATCHING-7COLORS-WHITE	0 (R,G,B)		VXX: C7CS6=0000, 0000, 0000	QVX: C7CS6	C7CS6=0000, 0000, 0000		✓
		2048(R,G,B)		VXX: C7CS6=2048, 2048, 2048		C7CS6=2048, 2048, 2048		✓
	COLOR MATCHING-7COLORS-AUTO TESTPATTERN	OFF		VXX: CATI1=+00000	QVX: CATI1	CATI1=+00000		✓
		ON		VXX: CATI1=+00001		CATI1=+00001		✓
	COLOR CORRECTION	OFF		VCM: 0	QMC	0		✓
		USER		VCM: 1		1		✓
	COLOR CORRECTION-RED	-30		VXX: CCRI0=-00030	QVX: CCRI0	CCRI0=-00030		✓
		+30		VXX: CCRI0=+00030		CCRI0=+00030		✓
	COLOR CORRECTION-GREEN	-30		VXX: CCRI1=-00030	QVX: CCRI1	CCRI1=-00030		✓
		+30		VXX: CCRI1=+00030		CCRI1=+00030		✓
	COLOR CORRECTION-BLUE	-30		VXX: CCRI2=-00030	QVX: CCRI2	CCRI2=-00030		✓
		+30		VXX: CCRI2=+00030		CCRI2=+00030		✓
	COLOR CORRECTION-CYAN	-30		VXX: CCRI3=-00030	QVX: CCRI3	CCRI3=-00030		✓
		+30		VXX: CCRI3=+00030		CCRI3=+00030		✓
	COLOR CORRECTION-MAGENTA	-30		VXX: CCRI4=-00030	QVX: CCRI4	CCRI4=-00030		✓
		+30		VXX: CCRI4=+00030		CCRI4=+00030		✓
	COLOR CORRECTION-YELLOW	-30		VXX: CCRI5=-00030	QVX: CCRI5	CCRI5=-00030		✓
		+30		VXX: CCRI5=+00030		CCRI5=+00030		✓
	AUTO SIGNAL	OFF		VXX: AASIO=+00000	QVX: AASIO	AASIO=+00000		✓
		ON		VXX: AASIO=+00001		AASIO=+00001		✓
	AUTO SETUP -MODE	USER		OAM: 0	QAM	0		✓
		DEFAULT		OAM: 1		1		✓
		WIDE		OAM: 2		2		✓
	AUTO SETUP -POSITION ADJ.	OFF		VXX: APAI0=+00000	QVX: APAI0	APAI0=+00000		✓
		ON		VXX: APAI0=+00001		APAI0=+00001		✓
	RGB IN-RGB1 SYNC SLICE LEVEL	LOW		VXX: STRI0=+00000	QVX: STRI0	STRI0=+00000		✓
		HIGH		VXX: STRI0=+00001		STRI0=+00001		✓
	RGB IN-RGB1 EDID MODE	DEFAULT		VXX: EDM17=+00000	QVX: EDM17	EDM17=+00000		✓
		SCREEB FIT		VXX: EDM17=+00001		EDM17=+00001		✓
		USER		VXX: EDM17=+00010		EDM17=+00010		✓
	RGB IN-RGB1 EDID RESOLUTION	1024x768p		VXX: EDRS7=1024: 0768: p	QVX: EDRS7	EDRS7=1024: 0768: p		✓
		1280x720p		VXX: EDRS7=1280: 0720: p		EDRS7=1280: 0720: p		✓
		1280x800p		VXX: EDRS7=1280: 0800: p		EDRS7=1280: 0800: p		✓
		1280x1024p		VXX: EDRS7=1280: 1024: p		EDRS7=1280: 1024: p		✓
		1366x768p		VXX: EDRS7=1366: 0768: p		EDRS7=1366: 0768: p		✓
		1400x1050p		VXX: EDRS7=1400: 1050: p		EDRS7=1400: 1050: p		✓
		1440x900p		VXX: EDRS7=1440: 0900: p		EDRS7=1440: 0900: p		✓
		1600x900p		VXX: EDRS7=1600: 0900: p		EDRS7=1600: 0900: p		✓
		1600x1200p		VXX: EDRS7=1600: 1200: p		EDRS7=1600: 1200: p		✓
		1680x1050p		VXX: EDRS7=1680: 1050: p		EDRS7=1680: 1050: p		✓
		1920x1080p		VXX: EDRS7=1920: 1080: p		EDRS7=1920: 1080: p		✓
		1920x1080i		VXX: EDRS7=1920: 1080: i		EDRS7=1920: 1080: i		✓
		1920x1200p		VXX: EDRS7=1920: 1200: p		EDRS7=1920: 1200: p		✓
	RGB IN-RGB1 EDID VERTICAL SCAN FREQUENCY	60Hz		VXX: EDVI7=+06000	QVX: EDVI7	EDVI7=+06000		✓
		50Hz		VXX: EDVI7=+05000		EDVI7=+05000		✓
		48Hz		VXX: EDVI7=+04800		EDVI7=+04800		✓
		30Hz		VXX: EDVI7=+03000		EDVI7=+03000		✓
		25Hz		VXX: EDVI7=+02500		EDVI7=+02500		✓
		24Hz		VXX: EDVI7=+02400		EDVI7=+02400		✓
	RGB IN-RGB1 EDID RESOLUTION / VERTICAL SCAN FREQUENCY	* PARAMETER		VXX: EDGS1=*****: *: ****	QVX: EDGS1	EDGS1=*****: *: ****		✓
		1024x768		VXX: EDGS1=1024: 0768: *: ****		EDGS1=1024: 0768: *: ****		✓
		1280x720		VXX: EDGS1=1280: 0720: *: ****		EDGS1=1280: 0720: *: ****		✓
		1280x800		VXX: EDGS1=1280: 0800: *: ****		EDGS1=1280: 0800: *: ****		✓
		1280x1024		VXX: EDGS1=1280: 1024: *: ****		EDGS1=1280: 1024: *: ****		✓
		1366x768		VXX: EDGS1=1366: 0768: *: ****		EDGS1=1366: 0768: *: ****		✓
		1400x1050		VXX: EDGS1=1400: 1050: *: ****		EDGS1=1400: 1050: *: ****		✓
		1440x900		VXX: EDGS1=1440: 0900: *: ****		EDGS1=1440: 0900: *: ****		✓
		1600x900		VXX: EDGS1=1600: 0900: *: ****		EDGS1=1600: 0900: *: ****		✓
		1600x1200		VXX: EDGS1=1600: 1200: *: ****		EDGS1=1600: 1200: *: ****		✓
		1680x1050		VXX: EDGS1=1680: 1050: *: ****		EDGS1=1680: 1050: *: ****		✓
		1920x1080		VXX: EDGS1=1920: 1080: *: ****		EDGS1=1920: 1080: *: ****		✓
		1920x1200		VXX: EDGS1=1920: 1200: *: ****		EDGS1=1920: 1200: *: ****		✓
		* PARAMETER2	Progressive Interlace	VXX: EDGS1=*****: p: ****		EDGS1=*****: p: ****		✓
				VXX: EDGS1=*****: i: ****		EDGS1=*****: i: ****		✓
		* PARAMETER3	60Hz	VXX: EDGS1=*****: *: 6000		EDGS1=*****: *: 6000		✓
			50Hz	VXX: EDGS1=*****: *: 5000		EDGS1=*****: *: 5000		✓
			48Hz	VXX: EDGS1=*****: *: 4800		EDGS1=*****: *: 4800		✓
			30Hz	VXX: EDGS1=*****: *: 3000		EDGS1=*****: *: 3000		✓
			25Hz	VXX: EDGS1=*****: *: 2500		EDGS1=*****: *: 2500		✓
			24Hz	VXX: EDGS1=*****: *: 2400		EDGS1=*****: *: 2400		✓
	RGB IN-RGB1 EDID STATUS RESOLUTION / VERTICAL SCAN FREQUENCY	* PARAMETER			QVX: ESGS1	ESGS1=*****: *: ****		✓
		1024x768				ESGS1=1024: 0768: *: ****		✓
		1280x720				ESGS1=1280: 0720: *: ****		✓
		1280x800				ESGS1=1280: 0800: *: ****		✓
		1280x1024				ESGS1=1280: 1024: *: ****		✓
		1366x768				ESGS1=1366: 0768: *: ****		✓
		1400x1050				ESGS1=1400: 1050: *: ****		✓

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK		
		* PARAMETER1	1440x900	VXX:EDRS1=1440:0900:p:****	ESGS1=1440:0900:*:****	✓		
			1600x900	VXX:EDRS1=1600:0900:p:****	ESGS1=1600:0900:*:****	✓		
			1600x1200	VXX:EDRS1=1600:1200:p:****	ESGS1=1600:1200:*:****	✓		
			1680x1050	VXX:EDRS1=1680:1050:p:****	ESGS1=1680:1050:*:****	✓		
			1920x1080	VXX:EDRS1=1920:1080:p:****	ESGS1=1920:1080:*:****	✓		
		1920x1200	VXX:EDRS1=1920:1200:p:****	ESGS1=1920:1200:*:****	✓			
		* PARAMETER2	Progressive Interlace	VXX:EDRS1=*****:p:****	ESGS1=*****:p:****	✓		
			60Hz	VXX:EDRS1=*****:j:****	ESGS1=*****:j:****	✓		
			50Hz	VXX:EDRS1=*****:s:6000	ESGS1=*****:s:6000	✓		
			48Hz	VXX:EDRS1=*****:s:5000	ESGS1=*****:s:5000	✓		
			30Hz	VXX:EDRS1=*****:s:4800	ESGS1=*****:s:4800	✓		
		* PARAMETER3	30Hz	VXX:EDRS1=*****:s:3000	ESGS1=*****:s:3000	✓		
			25Hz	VXX:EDRS1=*****:s:2500	ESGS1=*****:s:2500	✓		
			24Hz	VXX:EDRS1=*****:s:2400	ESGS1=*****:s:2400	✓		
			HDMI IN-EDID MODE	DEFAULT	VXX:EDMI3=+00000	QVX:EDMI3	EDMI3=+00000	✓
SCREEN FIT	VXX:EDMI3=+00001		EDMI3=+00001	✓				
USER	VXX:EDMI3=+00010	EDMI3=+00010	✓					
HDMI IN-EDID RESOLUTION	1024x768p	VXX:EDRS3=1024:0768:p	QVX:EDRS3	EDRS3=1024:0768:p	✓			
	1280x720p	VXX:EDRS3=1280:0720:p	EDRS3=1280:0720:p	✓				
	1280x768p	VXX:EDRS3=1280:0768:p	EDRS3=1280:0768:p	✓				
	1280x800p	VXX:EDRS3=1280:0800:p	EDRS3=1280:0800:p	✓				
	1280x1024p	VXX:EDRS3=1280:1024:p	EDRS3=1280:1024:p	✓				
	1366x768p	VXX:EDRS3=1366:0768:p	EDRS3=1366:0768:p	✓				
	1400x1050p	VXX:EDRS3=1400:1050:p	EDRS3=1400:1050:p	✓				
	1440x900p	VXX:EDRS3=1440:0900:p	EDRS3=1440:0900:p	✓				
	1600x900p	VXX:EDRS3=1600:0900:p	EDRS3=1600:0900:p	✓				
	1600x1200p	VXX:EDRS3=1600:1200:p	EDRS3=1600:1200:p	✓				
	1680x1050p	VXX:EDRS3=1680:1050:p	EDRS3=1680:1050:p	✓				
	1920x1080p	VXX:EDRS3=1920:1080:p	EDRS3=1920:1080:p	✓				
	1920x1080i	VXX:EDRS3=1920:1080:i	EDRS3=1920:1080:i	✓				
	1920x1200p	VXX:EDRS3=1920:1200:p	EDRS3=1920:1200:p	✓				
	HDMI IN-EDID VERTICAL SCAN FREQUENCY	60Hz	VXX:EDVI3=+06000	QVX:EDVI3	EDVI3=+06000	✓		
50Hz		VXX:EDVI3=+05000	EDVI3=+05000	✓				
48Hz		VXX:EDVI3=+04800	EDVI3=+04800	✓				
30Hz		VXX:EDVI3=+03000	EDVI3=+03000	✓				
25Hz		VXX:EDVI3=+02500	EDVI3=+02500	✓				
24Hz	VXX:EDVI3=+02400	EDVI3=+02400	✓					
HDMI IN-HDMI1 EDID RESOLUTION / VERTICAL SCAN FREQUENCY	* PARAMETER	VXX:EDHS1=*****:s:****	QVX:EDHS1	EDHS1=*****:s:****	✓			
	* PARAMETER1	1024x768	VXX:EDHS1=1024:0768:s:****	EDHS1=1024:0768:s:****	✓			
		1280x720	VXX:EDHS1=1280:0720:s:****	EDHS1=1280:0720:s:****	✓			
		1280x768	VXX:EDHS1=1280:0768:s:****	EDHS1=1280:0768:s:****	✓			
		1280x800	VXX:EDHS1=1280:0800:s:****	EDHS1=1280:0800:s:****	✓			
		1280x1024	VXX:EDHS1=1280:1024:s:****	EDHS1=1280:1024:s:****	✓			
		1366x768	VXX:EDHS1=1366:0768:s:****	EDHS1=1366:0768:s:****	✓			
		1400x1050	VXX:EDHS1=1400:1050:s:****	EDHS1=1400:1050:s:****	✓			
		1440x900	VXX:EDHS1=1440:0900:s:****	EDHS1=1440:0900:s:****	✓			
		1600x900	VXX:EDHS1=1600:0900:s:****	EDHS1=1600:0900:s:****	✓			
		1600x1200	VXX:EDHS1=1600:1200:s:****	EDHS1=1600:1200:s:****	✓			
		1680x1050	VXX:EDHS1=1680:1050:s:****	EDHS1=1680:1050:s:****	✓			
		1920x1080	VXX:EDHS1=1920:1080:s:****	EDHS1=1920:1080:s:****	✓			
		1920x1200	VXX:EDHS1=1920:1200:s:****	EDHS1=1920:1200:s:****	✓			
		* PARAMETER2	Progressive Interlace	VXX:EDHS1=*****:p:****	EDHS1=*****:p:****	✓		
		60Hz	VXX:EDHS1=*****:j:****	EDHS1=*****:j:****	✓			
	50Hz	VXX:EDHS1=*****:s:06000	EDHS1=*****:s:06000	✓				
	48Hz	VXX:EDHS1=*****:s:05000	EDHS1=*****:s:05000	✓				
	30Hz	VXX:EDHS1=*****:s:04800	EDHS1=*****:s:04800	✓				
	25Hz	VXX:EDHS1=*****:s:03000	EDHS1=*****:s:03000	✓				
24Hz	VXX:EDHS1=*****:s:02500	EDHS1=*****:s:02500	✓					
24Hz	VXX:EDHS1=*****:s:02400	EDHS1=*****:s:02400	✓					
HDMI IN-HDMI1 SIGNAL LEVEL	0-1023	VXX:HSLI1=+00000	QVX:HSLI1	HSLI1=+00000	✓			
64-940	VXX:HSLI1=+00001	HSLI1=+00001	✓					
AUTO	VXX:HSLI1=+00002	HSLI1=+00002	✓					
HDMI IN-HDMI2 SIGNAL LEVEL	0-1023	VXX:HSLI2=+00000	QVX:HSLI2	HSLI2=+00000	✓			
64-940	VXX:HSLI2=+00001	HSLI2=+00001	✓					
AUTO	VXX:HSLI2=+00002	HSLI2=+00002	✓					
HDMI IN-HDMI3 SIGNAL LEVEL	0-1023	VXX:HSLI3=+00000	QVX:HSLI3	HSLI3=+00000	✓			
64-940	VXX:HSLI3=+00001	HSLI3=+00001	✓					
AUTO	VXX:HSLI3=+00002	HSLI3=+00002	✓					
HDMI IN-HDMI1 EDID SELECT	4K/60p	VXX:HESI1=+00000	QVX:HESI1	HESI1=+00000	✓			
4K/30p	VXX:HESI1=+00001	HESI1=+00001	✓					
2K	VXX:HESI1=+00002	HESI1=+00002	✓					
HDMI IN-HDMI2 EDID SELECT	4K/60p	VXX:HESI2=+00000	QVX:HESI2	HESI2=+00000	✓			
4K/30p	VXX:HESI2=+00001	HESI2=+00001	✓					
2K	VXX:HESI2=+00002	HESI2=+00002	✓					
HDMI IN-HDMI3 EDID SELECT	4K/60p	VXX:HESI3=+00000	QVX:HESI3	HESI3=+00000	✓			
4K/30p	VXX:HESI3=+00001	HESI3=+00001	✓					
2K	VXX:HESI3=+00002	HESI3=+00002	✓					
HDMI IN-HDMI2 EDID MODE	DEFAULT	VXX:EDMI6=+00000	QVX:EDMI6	EDMI6=+00000	✓			
SCREEN FIT	VXX:EDMI6=+00001	EDMI6=+00001	✓					
USER	VXX:EDMI6=+00010	EDMI6=+00010	✓					
HDMI IN-HDMI2 EDID RESOLUTION	1024x768p	VXX:EDRS6=1024:0768:p	QVX:EDRS3	EDRS6=1024:0768:p	✓			
	1280x720p	VXX:EDRS6=1280:0720:p	EDRS6=1280:0720:p	✓				
	1280x768p	VXX:EDRS6=1280:0768:p	EDRS6=1280:0768:p	✓				
	1280x800p	VXX:EDRS6=1280:0800:p	EDRS6=1280:0800:p	✓				
	1280x1024p	VXX:EDRS6=1280:1024:p	EDRS6=1280:1024:p	✓				
	1366x768p	VXX:EDRS6=1366:0768:p	EDRS6=1366:0768:p	✓				
	1400x1050p	VXX:EDRS6=1400:1050:p	EDRS6=1400:1050:p	✓				
	1440x900p	VXX:EDRS6=1440:0900:p	EDRS6=1440:0900:p	✓				
	1600x900p	VXX:EDRS6=1600:0900:p	EDRS6=1600:0900:p	✓				
	1600x1200p	VXX:EDRS6=1600:1200:p	EDRS6=1600:1200:p	✓				
	1680x1050p	VXX:EDRS6=1680:1050:p	EDRS6=1680:1050:p	✓				
	1920x1080p	VXX:EDRS6=1920:1080:p	EDRS6=1920:1080:p	✓				
	1920x1080i	VXX:EDRS6=1920:1080:i	EDRS6=1920:1080:i	✓				
	1920x1200p	VXX:EDRS6=1920:1200:p	EDRS6=1920:1200:p	✓				
	HDMI IN-HDMI2 EDID VERTICAL SCAN FREQUENCY	60Hz	VXX:EDVI6=+06000	QVX:EDVI6	EDVI6=+06000	✓		
50Hz		VXX:EDVI6=+05000	EDVI6=+05000	✓				
48Hz		VXX:EDVI6=+04800	EDVI6=+04800	✓				
30Hz		VXX:EDVI6=+03000	EDVI6=+03000	✓				
25Hz		VXX:EDVI6=+02500	EDVI6=+02500	✓				
24Hz	VXX:EDVI6=+02400	EDVI6=+02400	✓					
HDMI IN-HDMI2 EDID RESOLUTION / VERTICAL SCAN FREQUENCY	* PARAMETER	VXX:EDHS2=*****:s:****	QVX:EDHS2	EDHS2=*****:s:****	✓			
	* PARAMETER1	1024x768	VXX:EDHS2=1024:0768:s:****	EDHS2=1024:0768:s:****	✓			
		1280x720	VXX:EDHS2=1280:0720:s:****	EDHS2=1280:0720:s:****	✓			
		1280x768	VXX:EDHS2=1280:0768:s:****	EDHS2=1280:0768:s:****	✓			
		1280x800	VXX:EDHS2=1280:0800:s:****	EDHS2=1280:0800:s:****	✓			
		1280x1024	VXX:EDHS2=1280:1024:s:****	EDHS2=1280:1024:s:****	✓			
		1366x768	VXX:EDHS2=1366:0768:s:****	EDHS2=1366:0768:s:****	✓			
		1400x1050	VXX:EDHS2=1400:1050:s:****	EDHS2=1400:1050:s:****	✓			
		1440x900	VXX:EDHS2=1440:0900:s:****	EDHS2=1440:0900:s:****	✓			
		1600x900	VXX:EDHS2=1600:0900:s:****	EDHS2=1600:0900:s:****	✓			
		1600x1200	VXX:EDHS2=1600:1200:s:****	EDHS2=1600:1200:s:****	✓			
		1680x1050	VXX:EDHS2=1680:1050:s:****	EDHS2=1680:1050:s:****	✓			
		1920x1080	VXX:EDHS2=1920:1080:s:****	EDHS2=1920:1080:s:****	✓			
		1920x1200	VXX:EDHS2=1920:1200:s:****	EDHS2=1920:1200:s:****	✓			
		* PARAMETER2	Progressive Interlace	VXX:EDHS2=*****:p:****	EDHS2=*****:p:****	✓		
		60Hz	VXX:EDHS2=*****:j:****	EDHS2=*****:j:****	✓			
	50Hz	VXX:EDHS2=*****:s:06000	EDHS2=*****:s:06000	✓				
	50Hz	VXX:EDHS2=*****:s:05000	EDHS2=*****:s:05000	✓				

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK		
DISPLAY OPTION			48Hz	VXX: EDHS2=*****: *:04800		EDHS2=*****: *:04800	✓	
			30Hz	VXX: EDHS2=*****: *:03000		EDHS2=*****: *:03000	✓	
			25Hz	VXX: EDHS2=*****: *:02500		EDHS2=*****: *:02500	✓	
			24Hz	VXX: EDHS2=*****: *:02400		EDHS2=*****: *:02400	✓	
	HDMI IN-HDMI3 EDID MODE	DEFAULT		VXX: EDMIA=+00000	QVX: EDMIA	EDMIA=+00000	✓	
		SCREEN FIT		VXX: EDMIA=+00001		EDMIA=+00001	✓	
		USER		VXX: EDMIA=+00010		EDMIA=+00010	✓	
	HDMI IN-HDMI3 EDID RESOLUTION	1024x768p		VXX: EDRSA=1024:0768: p	QVX: EDRSA	EDRSA=1024:0768: p	✓	
		1280x720p		VXX: EDRSA=1280:0720: p		EDRSA=1280:0720: p	✓	
		1280x768p		VXX: EDRSA=1280:0768: p		EDRSA=1280:0768: p	✓	
		1280x800p		VXX: EDRSA=1280:0800: p		EDRSA=1280:0800: p	✓	
		1280x1024p		VXX: EDRSA=1280:1024: p		EDRSA=1280:1024: p	✓	
		1366x768p		VXX: EDRSA=1366:0768: p		EDRSA=1366:0768: p	✓	
		1400x1050p		VXX: EDRSA=1400:1050: p		EDRSA=1400:1050: p	✓	
		1440x900p		VXX: EDRSA=1440:0900: p		EDRSA=1440:0900: p	✓	
		1600x900p		VXX: EDRSA=1600:0900: p		EDRSA=1600:0900: p	✓	
		1600x1200p		VXX: EDRSA=1600:1200: p		EDRSA=1600:1200: p	✓	
		1680x1050p		VXX: EDRSA=1680:1050: p		EDRSA=1680:1050: p	✓	
		1920x1080p		VXX: EDRSA=1920:1080: p		EDRSA=1920:1080: p	✓	
		1920x1080i		VXX: EDRSA=1920:1080: i		EDRSA=1920:1080: i	✓	
		1920x1200p		VXX: EDRSA=1920:1200: p		EDRSA=1920:1200: p	✓	
	HDMI IN-HDMI3 EDID VERTICAL SCAN FREQUENCY	60Hz		VXX: EDVIA=+06000	QVX: EDVIA	EDVIA=+06000	✓	
		50Hz		VXX: EDVIA=+05000		EDVIA=+05000	✓	
		48Hz		VXX: EDVIA=+04800		EDVIA=+04800	✓	
		30Hz		VXX: EDVIA=+03000		EDVIA=+03000	✓	
	25Hz		VXX: EDVIA=+02500		EDVIA=+02500	✓		
	24Hz		VXX: EDVIA=+02400		EDVIA=+02400	✓		
HDMI IN-HDMI3 EDID RESOLUTION / VERTICAL SCAN FREQUENCY	* PARAMETER		VXX: EDHS3=*****: *:****	QVX: EDHS3	EDHS3=*****: *:****	✓		
	* PARAMETER1	1024x768	VXX: EDHS3=1024:0768: *:****		EDHS3=1024:0768: *:****	✓		
		1280x720	VXX: EDHS3=1280:0720: *:****		EDHS3=1280:0720: *:****	✓		
		1280x768	VXX: EDHS3=1280:0768: *:****		EDHS3=1280:0768: *:****	✓		
		1280x800	VXX: EDHS3=1280:0800: *:****		EDHS3=1280:0800: *:****	✓		
		1280x1024	VXX: EDHS3=1280:1024: *:****		EDHS3=1280:1024: *:****	✓		
		1366x768	VXX: EDHS3=1366:0768: *:****		EDHS3=1366:0768: *:****	✓		
		1400x1050	VXX: EDHS3=1400:1050: *:****		EDHS3=1400:1050: *:****	✓		
		1440x900	VXX: EDHS3=1440:0900: *:****		EDHS3=1440:0900: *:****	✓		
		1600x900	VXX: EDHS3=1600:0900: *:****		EDHS3=1600:0900: *:****	✓		
		1600x1200	VXX: EDHS3=1600:1200: *:****		EDHS3=1600:1200: *:****	✓		
	* PARAMETER2	Progressive	VXX: EDHS3=*****: p:****		EDHS3=*****: p:****	✓		
		Interlace	VXX: EDHS3=*****: i:****		EDHS3=*****: i:****	✓		
		* PARAMETER3	60Hz	VXX: EDHS3=*****: *:6000		EDHS3=*****: *:6000	✓	
			50Hz	VXX: EDHS3=*****: *:5000		EDHS3=*****: *:5000	✓	
			48Hz	VXX: EDHS3=*****: *:4800		EDHS3=*****: *:4800	✓	
	30Hz		VXX: EDHS3=*****: *:3000		EDHS3=*****: *:3000	✓		
		25Hz	VXX: EDHS3=*****: *:2500		EDHS3=*****: *:2500	✓		
		24Hz	VXX: EDHS3=*****: *:2400		EDHS3=*****: *:2400	✓		
DIGITAL LINK-SIGNAL LEVEL	AUTO		VXX: DKLI1=+00000	QVX: DKLI1	DKLI1=+00000	✓		
	0-1023		VXX: DKLI1=+00001		DKLI1=+00001	✓		
	64-940		VXX: DKLI1=+00002		DKLI1=+00002	✓		
DIGITAL LINK-EDID MODE	DEFAULT		VXX: EDMIA4=+00000	QVX: EDMIA4	EDMIA4=+00000	✓		
	SCREEN FIT		VXX: EDMIA4=+00001		EDMIA4=+00001	✓		
	USER		VXX: EDMIA4=+00010		EDMIA4=+00010	✓		
DIGITAL LINK-EDID RESOLUTION	1024x768p		VXX: EDRS4=1024:0768: p	QVX: EDRS4	EDRS4=1024:0768: p	✓		
	1280x720p		VXX: EDRS4=1280:0720: p		EDRS4=1280:0720: p	✓		
	1280x768p		VXX: EDRS4=1280:0768: p		EDRS4=1280:0768: p	✓		
	1280x800p		VXX: EDRS4=1280:0800: p		EDRS4=1280:0800: p	✓		
	1280x1024p		VXX: EDRS4=1280:1024: p		EDRS4=1280:1024: p	✓		
	1366x768p		VXX: EDRS4=1366:0768: p		EDRS4=1366:0768: p	✓		
	1400x1050p		VXX: EDRS4=1400:1050: p		EDRS4=1400:1050: p	✓		
	1440x900p		VXX: EDRS4=1440:0900: p		EDRS4=1440:0900: p	✓		
	1600x900p		VXX: EDRS4=1600:0900: p		EDRS4=1600:0900: p	✓		
	1600x1200p		VXX: EDRS4=1600:1200: p		EDRS4=1600:1200: p	✓		
	1680x1050p		VXX: EDRS4=1680:1050: p		EDRS4=1680:1050: p	✓		
	1920x1080p		VXX: EDRS4=1920:1080: p		EDRS4=1920:1080: p	✓		
	1920x1080i		VXX: EDRS4=1920:1080: i		EDRS4=1920:1080: i	✓		
	1920x1200p		VXX: EDRS4=1920:1200: p		EDRS4=1920:1200: p	✓		
DIGITAL LINK-EDID VERTICAL SCAN FREQUENCY	60Hz		VXX: EDVIA4=+06000	QVX: EDVIA4	EDVIA4=+06000	✓		
	50Hz		VXX: EDVIA4=+05000		EDVIA4=+05000	✓		
	48Hz		VXX: EDVIA4=+04800		EDVIA4=+04800	✓		
	30Hz		VXX: EDVIA4=+03000		EDVIA4=+03000	✓		
	25Hz		VXX: EDVIA4=+02500		EDVIA4=+02500	✓		
	24Hz		VXX: EDVIA4=+02400		EDVIA4=+02400	✓		
DIGITAL LINK-EDID STATUS RESOLUTION / VERTICAL SCAN FREQUENCY	* PARAMETER		VXX: ESLS1=*****: *:****	QVX: ESLS1	ESLS1=*****: *:****	✓		
	* PARAMETER1	1024x768	VXX: ESLS1=1024:0768: *:****		ESLS1=1024:0768: *:****	✓		
		1280x720	VXX: ESLS1=1280:0720: *:****		ESLS1=1280:0720: *:****	✓		
		1280x768	VXX: ESLS1=1280:0768: *:****		ESLS1=1280:0768: *:****	✓		
		1280x800	VXX: ESLS1=1280:0800: *:****		ESLS1=1280:0800: *:****	✓		
		1280x1024	VXX: ESLS1=1280:1024: *:****		ESLS1=1280:1024: *:****	✓		
		1366x768	VXX: ESLS1=1366:0768: *:****		ESLS1=1366:0768: *:****	✓		
		1400x1050	VXX: ESLS1=1400:1050: *:****		ESLS1=1400:1050: *:****	✓		
		1440x900	VXX: ESLS1=1440:0900: *:****		ESLS1=1440:0900: *:****	✓		
		1600x900	VXX: ESLS1=1600:0900: *:****		ESLS1=1600:0900: *:****	✓		
		1600x1200	VXX: ESLS1=1600:1200: *:****		ESLS1=1600:1200: *:****	✓		
	* PARAMETER2	Progressive	VXX: ESLS1=*****: p:****		ESLS1=*****: p:****	✓		
		Interlace	VXX: ESLS1=*****: i:****		ESLS1=*****: i:****	✓		
		* PARAMETER3	60Hz	VXX: ESLS1=*****: *:6000		ESLS1=*****: *:6000	✓	
			50Hz	VXX: ESLS1=*****: *:5000		ESLS1=*****: *:5000	✓	
			48Hz	VXX: ESLS1=*****: *:4800		ESLS1=*****: *:4800	✓	
	30Hz		VXX: ESLS1=*****: *:3000		ESLS1=*****: *:3000	✓		
		25Hz	VXX: ESLS1=*****: *:2500		ESLS1=*****: *:2500	✓		
		24Hz	VXX: ESLS1=*****: *:2400		ESLS1=*****: *:2400	✓		
INPUT GUIDE	OFF		OID:0	QDI	0	✓		
	ON (SIMPLE)		OID:1		1	✓		
OSD POSITION	UPPER LEFT		ODP:1	QDP	1	✓		
	CETRE LEFT		ODP:2		2	✓		
	LOWER LEFT		ODP:3		3	✓		
	TOP CENTER		ODP:4		4	✓		
	CENTER		ODP:5		5	✓		
	LOEER CENTER		ODP:6		6	✓		
	UPPER RIGHT		ODP:7		7	✓		
	CENTER RIGHT		ODP:8		8	✓		
	LOWER RIGHT		ODP:9		9	✓		
OSD ROTATION	OFF		VXX: OSRI1=+00000	QVX: OSRI1	OSRI1=+00000	✓		
	CLOCKWISE		VXX: OSRI1=+00001		OSRI1=+00001	✓		
	COUNTER CLOCKWISE		VXX: OSRI1=+00002		OSRI1=+00002	✓		
OSD MEMORY	OFF		VXX: OMYI0=+00000	QVX: OMYI0	OMYI0=+00000	✓		
	ON		VXX: OMYI0=+00001		OMYI0=+00001	✓		
ON SCREEN	OFF		OOS:0	QOS	0	✓		
	ON		OOS:1		1	✓		
OSD SIZE	NORMAL		VXX: OSZI1=+00100	QVX: OSZI1	OSZI1=+00100	✓		
	DOUBLE		VXX: OSZI1=+00200		OSZI1=+00200	✓		
WARNING MESSAGE	OFF		VXX: WMDI0=+00000	QVX: WMDI0	WMDI0=+00000	✓		

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES	
				COMMANDS/CALL BACK	COMMANDS	CALL BACK			
	OSD DESIGN	ON		VXX:WMDI0=+00001		WMDI0=+00001		✓	
		1(YELLOW)		MOD:0	QOD	0		✓	
		2(BLUE)		MOD:1		1		✓	
		3(WHITE)		MOD:2		2		✓	
		4(GREEN)		MOD:3		3		✓	
		5(PEACH)		MOD:4		4		✓	
	CLOSED CAPTION SETTING	OFF		OCC:0	QCC	0		✓	
		CC1		OCC:1		1		✓	
		CC2		OCC:2		2		✓	
		CC3		OCC:3		3		✓	
		CC4		OCC:4		4		✓	
	SCREEN SETTING	16:10		VSF:0	QSF	0		✓	
		16:9		VSF:1		1		✓	
		4:3		VSF:2		2		✓	
	SCREEN POSITION-VERTICAL	min.		VXX:VSPI0=-00120	QVX:VSPI0	VSPI0=-00120		-60	
		max.		VXX:VSPI0=+00120		VSPI0=+00120		60	
	SCREEN POSITION-HORIZONTAL	min.		VXX:HSPI0=-00320	QVX:HSPI0	HSPI0=-00320		-160	
		max.		VXX:HSPI0=+00320		HSPI0=+00320		+160	
	STARTUP LOGO	OFF		MLO:0	QLO	0		✓	
		USER LOGO		MLO:1		1		✓	
		DEFAULT LOGO		MLO:2		2		✓	
	UNIFORMITY - USER CORRECTION - ADJUSTMENT LEVEL	min.		VXX:UFMI4=+00001	QVX:UFMI4	UFMI4=+00001		✓	
		max.		VXX:UFMI4=+00007		UFMI4=+00007		✓	
	UNIFORMITY - USER CORRECTION - TEST PATTERN	OFF		VXX:UFMI5=+00000	QVX:UFMI5	UFMI5=+00000		✓	
		ON		VXX:UFMI5=+00001		UFMI5=+00001		✓	
	UNIFORMITY - USER CORRECTION - ADJUSTMENT POSITION	* PARAMETER		VXX:UFMS6=*:*:*****	QVX:UFMS6=*:*	UFMS6=*:*:*****		✓	
		* PARAMETER1	UPPER LEFT		VXX:UFMS6=0:*:*****		UFMS6=0:*:*****		✓
			UPPER RIGHT		VXX:UFMS6=1:*:*****		UFMS6=1:*:*****		✓
			LOWER LEFT		VXX:UFMS6=2:*:*****		UFMS6=2:*:*****		✓
			LOWER RIGHT		VXX:UFMS6=3:*:*****		UFMS6=3:*:*****		✓
			UPPER		VXX:UFMS6=4:*:*****		UFMS6=4:*:*****		✓
			LOWER		VXX:UFMS6=5:*:*****		UFMS6=5:*:*****		✓
			LEFT		VXX:UFMS6=6:*:*****		UFMS6=6:*:*****		✓
		RIGHT		VXX:UFMS6=7:*:*****		UFMS6=7:*:*****		✓	
		* PARAMETER2	RED		VXX:UFMS6=*:R:*****		UFMS6=*:R:*****		✓
			GREEN		VXX:UFMS6=*:G:*****		UFMS6=*:G:*****		✓
			BLUE		VXX:UFMS6=*:B:*****		UFMS6=*:B:*****		✓
		* PARAMETER3	min.		VXX:UFMS6=*:*:-00031		UFMS6=*:*:-00031		✓
	0			VXX:UFMS6=*:*:+00000		UFMS6=*:*:+00000		✓	
	max.		VXX:UFMS6=*:*:+00031		UFMS6=*:*:+00031		✓		
	UNIFORMITY - USER CORRECTION - ADJUSTMENT POSITION - INITIALIZE	EXECUTE		VXX:UFMI7=+00001				✓	
	UNIFORMITY-WHITE/RED/GREEN/RED	* PARAMETER		E\$W:* ,*** ,*** ,**	E\$R:* ,**	** ,*** ,***		✓	
		* PARAMETER 1	WHITE		E\$W:W ,*** ,*** ,**	E\$R:W ,**	** ,*** ,***		✓
			RED		E\$W:R ,*** ,*** ,**	E\$R:R ,**	** ,*** ,***		✓
			GREEN		E\$W:G ,*** ,*** ,**	E\$R:G ,**	** ,*** ,***		✓
BLUE				E\$W:B ,*** ,*** ,**	E\$R:B ,**	** ,*** ,***		✓	
* PARAMETER 2		VERTICAL(-127)		E\$W:* , -127 ,*** ,**	E\$R:* ,**	** , -127 ,***		✓	
		VERTICAL(+127)		E\$W:* , +127 ,*** ,**	E\$R:* ,**	** , +127 ,***		✓	
* PARAMETER 3		HORIZONTAL(-127)		E\$W:* ,*** , -127 ,**	E\$R:* ,**	** ,*** , -127		✓	
		HORIZONTAL(+127)		E\$W:* ,*** , +127 ,**	E\$R:* ,**	** ,*** , +127		✓	
* PARAMETER 4		L1(OFF)		E\$W:* ,*** ,*** ,0*	E\$R:* ,0*	0* ,*** ,***		✓	
		L1(ON)		E\$W:* ,*** ,*** ,1*	E\$R:* ,1*	1* ,*** ,***		✓	
		L2(OFF)		E\$W:* ,*** ,*** ,*0	E\$R:* ,*0	*0 ,*** ,***		✓	
		L2(ON)		E\$W:* ,*** ,*** ,*1	E\$R:* ,*1	*1 ,*** ,***		✓	
UNIFORMITY-WHITE/RED/GREEN/RED		* PARAMETER		E\$W:* ,*** ,***	E\$R:*	** ,*** ,***		✓	
		* PARAMETER 1	WHITE		E\$W:W ,*** ,***	E\$R:W	** ,*** ,***		✓
			RED		E\$W:R ,*** ,***	E\$R:R	** ,*** ,***		✓
			GREEN		E\$W:G ,*** ,***	E\$R:G	** ,*** ,***		✓
	BLUE			E\$W:B ,*** ,***	E\$R:B	** ,*** ,***		✓	
	* PARAMETER 2	VERTICAL(-127)		E\$W:* , -127 ,***		** , -127 ,***		✓	
		VERTICAL(+127)		E\$W:* , +127 ,***		** , +127 ,***		✓	
	* PARAMETER 3	HORIZONTAL(-127)		E\$W:* ,*** , -127		** ,*** , -127		✓	
		HORIZONTAL(+127)		E\$W:* ,*** , +127		** ,*** , +127		✓	
	* PARAMETER 4	L1(OFF)				0* ,*** ,***		✓	
L1(ON)					1* ,*** ,***		✓		
L2(OFF)					*0 ,*** ,***		✓		
L2(ON)					*1 ,*** ,***		✓		
SHUTTER SETTING-FADE IN	0.0s(OFF)		VXX:SEFS1=0.0	QVX:SEFS1	SEFS1=0.0		✓		
	0.5s		VXX:SEFS1=0.5		SEFS1=0.5		✓		
	1.0s		VXX:SEFS1=1.0		SEFS1=1.0		✓		
	1.5s		VXX:SEFS1=1.5		SEFS1=1.5		✓		
	2.0s		VXX:SEFS1=2.0		SEFS1=2.0		✓		
	2.5s		VXX:SEFS1=2.5		SEFS1=2.5		✓		
	3.0s		VXX:SEFS1=3.0		SEFS1=3.0		✓		
	3.5s		VXX:SEFS1=3.5		SEFS1=3.5		✓		
	4.0s		VXX:SEFS1=4.0		SEFS1=4.0		✓		
	5.0s		VXX:SEFS1=5.0		SEFS1=5.0		✓		
	7.0s		VXX:SEFS1=7.0		SEFS1=7.0		✓		
10.0s		VXX:SEFS1=10.0		SEFS1=10.0		✓			
SHUTTER SETTING-FADE OUT	0.0s(OFF)		VXX:SEFS2=0.0	QVX:SEFS2	SEFS2=0.0		✓		
	0.5s		VXX:SEFS2=0.5		SEFS2=0.5		✓		
	1.0s		VXX:SEFS2=1.0		SEFS2=1.0		✓		
	1.5s		VXX:SEFS2=1.5		SEFS2=1.5		✓		
	2.0s		VXX:SEFS2=2.0		SEFS2=2.0		✓		
	2.5s		VXX:SEFS2=2.5		SEFS2=2.5		✓		
	3.0s		VXX:SEFS2=3.0		SEFS2=3.0		✓		
	3.5s		VXX:SEFS2=3.5		SEFS2=3.5		✓		
	4.0s		VXX:SEFS2=4.0		SEFS2=4.0		✓		
	5.0s		VXX:SEFS2=5.0		SEFS2=5.0		✓		
	7.0s		VXX:SEFS2=7.0		SEFS2=7.0		✓		
10.0s		VXX:SEFS2=10.0		SEFS2=10.0		✓			
SHUTTER SETTING-STARTUP	OPEN		VXX:SEFI3=+00000	QVX:SEFI3	SEFI3=+00000		✓		
	CLOSE		VXX:SEFI3=+00001		SEFI3=+00001		✓		
SHUTTER SETTING-SHUT OFF	OPEN		VXX:SEFI4=+00000	QVX:SEFI4	SEFI4=+00000		✓		
	CLOSE		VXX:SEFI4=+00001		SEFI4=+00001		✓		
	KEEP CURRENT STATE		VXX:SEFI4=+00002		SEFI4=+00002		✓		
SIGNAL SEARCH	OFF		OSR:0	QSR	0		✓		
	ON		OSR:1		1		✓		
BACK COLOR	BLUE		OBC:0	QBC	0		✓		
	BLACK		OBC:1		1		✓		
	DEFAULT LOGO		OBC:2		2		✓		
	USER LOGO		OBC:3		3		✓		
P-TIMER-MODE	COUNT DOWN		VXX:PTMI1=+00000	QVX:PTMI1	PTMI1=+00000		✓		
	COUNT UP		VXX:PTMI1=+00001		PTMI1=+00001		✓		
P-TIMER-COUNT DOWN TIMER	1 MIN.		VXX:PTMI2=+00001	QVX:PTMI2	PTMI2=+00001		✓		
	180 MIN.		VXX:PTMI2=+00180		PTMI2=+00180		✓		
P-TIMER-RESET	RESET		VXX:PTMI3=+00000				✓		
P-TIMER-EXIT	EXIT		VXX:PTMI4=+00000				✓		
STATUS			STS				✓		
PROJECTOR ID	0(ALL)		RIS:00				✓		
	64		RIS:64				✓		
PROJECTION METHOD INSTALLATION	FRONT/DESK		OIL:0	QSP	0		✓		
	REAR/DESK		OIL:1		1		✓		
	FRONT/CEILING		OIL:2		2		✓		
	REAR/CEILING		OIL:3		3		✓		
	FRONT/AUTO		OIL:4		4		✓		

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK		
	PROJECTION METHOD(AUTO)	REAR/AUTO		OIL : 5		5	✓	
		FRONT/DESK			QVX:PJMI2	PJMI2=+00000	✓	
		REAR/DESK				PJMI2=+00001	✓	
		FRONT/CEILING				PJMI2=+00002	✓	
	AUTO COOLING CONDITION-STATUS	REAR/CEILING				PJMI2=+00003	✓	
		FLOOR			QVX:ADRI1	ADRI1=+00000	✓	
		CEILING				ADRI1=+00001	✓	
		VERTICAL UP				ADRI1=+00002	✓	
	LIGHT POWER	VERTICAL DOWN				ADRI1=+00003	✓	
		PORTRAIT				ADRI1=+00004	✓	
		NORMAL		VXX:LPWI1=+00000	QLP	LPWI1=+00000	✓	
		ECO		VXX:LPWI1=+00001		LPWI1=+00001	✓	
	LIGHT OUTPUT	QUIET		VXX:LPWI1=+00040		LPWI1=+00040	✓	
		USER		VXX:LPWI1=+00100		LPWI1=+00100	✓	
	ECO MANAGEMENT-AMBIENT LIGHT DETECTION	min.		VXX:LOPI2=+00050	QVX:LOPI2	LOPI2=+00050	30%	
		max.		VXX:LOPI2=+01000		LOPI2=+01000	100%	
	ECO MANAGEMENT-SIGNAL DETECTION	OFF		VXX:ECOI1=+00000	QVX:ECOI1	ECOI1=+00000	✓	
		ON		VXX:ECOI1=+00001		ECOI1=+00001	✓	
	POWER MANAGEMENT	OFF		VXX:ECOI2=+00000	QVX:ECOI2	ECOI2=+00000	✓	
		ON		VXX:ECOI2=+00001		ECOI2=+00001	✓	
		READY		VXX:ECOI5=+00000	QVX:ECOI5	ECOI5=+00000	✓	
	POWER MANAGEMENT-TIMER	SHUTDOWN		VXX:ECOI5=+00001		ECOI5=+00001	✓	
		5 MIN		VXX:ECOI6=+00005	QVX:ECOI6	ECOI6=+00005	✓	
	STANDBY MODE	120 MIN		VXX:ECOI6=+00120		ECOI6=+00120	✓	
		NORMAL		VXX:STMI0=+00000	QVX:STMI0	STMI0=+00000	✓	
	QUICK STARTUP	ECO		VXX:STMI0=+00003		STMI0=+00003	✓	
		OFF		VXX:QSUI1=+00000	QVX:QSUI1	QSUI1=+00000	✓	
	QUICK STARTUP-VALID PERIOD	ON		VXX:QSUI1=+00001		QSUI1=+00001	✓	
		30MIN.		VXX:QSUI2=+00030	QVX:QSUI2	QSUI2=+00030	✓	
		60MIN.		VXX:QSUI2=+00060		QSUI2=+00060	✓	
	SCHEDULE	90MIN.		VXX:QSUI2=+00090		QSUI2=+00090	✓	
		OFF		VXX:SCHIO=+00000	QVX:SCHIO	SCHIO=+00000	✓	
	SCHEDULE-PROGRAM ASSIGN	ON		VXX:SCHIO=+00001		SCHIO=+00001	✓	
		OFF		VXX:SPGI*=+00000	QVX:SPGI*	SPGI*=+00000	✓	
		PROGRAM1		VXX:SPGI*=+00001		SPGI*=+00001	✓	
		PROGRAM2		VXX:SPGI*=+00002		SPGI*=+00002	✓	
		PROGRAM3		VXX:SPGI*=+00003		SPGI*=+00003	✓	
		PROGRAM4		VXX:SPGI*=+00004		SPGI*=+00004	✓	
		PROGRAM5		VXX:SPGI*=+00005		SPGI*=+00005	✓	
		PROGRAM6		VXX:SPGI*=+00006		SPGI*=+00006	✓	
		PROGRAM7		VXX:SPGI*=+00007		SPGI*=+00007	✓	
		* PARAMETER	SUN		VXX:SPGI0=+0000*	QVX:SPGI0	SPGI0=+0000*	✓
			MON		VXX:SPGI1=+0000*	QVX:SPGI1	SPGI1=+0000*	✓
			TUE		VXX:SPGI2=+0000*	QVX:SPGI2	SPGI2=+0000*	✓
			WED		VXX:SPGI3=+0000*	QVX:SPGI3	SPGI3=+0000*	✓
	THU		VXX:SPGI4=+0000*	QVX:SPGI4	SPGI4=+0000*	✓		
	FRI		VXX:SPGI5=+0000*	QVX:SPGI5	SPGI5=+0000*	✓		
	SAT		VXX:SPGI6=+0000*	QVX:SPGI6	SPGI6=+0000*	✓		
SCHEDULE-COMMAND SETTING	COMMAND Del		VXX:SCCS*=*00****	QVX:SCCS*=**	SCCS*=*00****	✓		
	STANDBY		VXX:SCCS*=*10****		SCCS*=*10****	✓		
	POWER ON		VXX:SCCS*=*11****		SCCS*=*11****	✓		
	SHUTTER OPEN		VXX:SCCS*=*20****		SCCS*=*20****	✓		
	SHUTTER CLOSE		VXX:SCCS*=*21****		SCCS*=*21****	✓		
	RGB1 INPUT		VXX:SCCS*=*31****		SCCS*=*31****	✓		
	RGB2 INPUT		VXX:SCCS*=*32****		SCCS*=*32****	✓		
	HDMI1 INPUT		VXX:SCCS*=*53****		SCCS*=*53****	✓		
	HDMI3 INPUT		VXX:SCCS*=*55****		SCCS*=*55****	✓		
	NORMAL		VXX:SCCS*=*70****		SCCS*=*70****	✓		
	ECO		VXX:SCCS*=*71****		SCCS*=*71****	✓		
	SILENT		VXX:SCCS*=*78****		SCCS*=*78****	✓		
	DIGITAL LINK		VXX:SCCS*=*B0****		SCCS*=*B0****	✓		
	INPUT 1		VXX:SCCS*=*B1****		SCCS*=*B1****	✓		
	INPUT 2		VXX:SCCS*=*B2****		SCCS*=*B2****	✓		
	INPUT 3		VXX:SCCS*=*B3****		SCCS*=*B3****	✓		
	INPUT 4		VXX:SCCS*=*B4****		SCCS*=*B4****	✓		
	INPUT 5		VXX:SCCS*=*B5****		SCCS*=*B5****	✓		
	INPUT 6		VXX:SCCS*=*B6****		SCCS*=*B6****	✓		
	INPUT 7		VXX:SCCS*=*B7****		SCCS*=*B7****	✓		
	INPUT 8		VXX:SCCS*=*B8****		SCCS*=*B8****	✓		
	INPUT 9		VXX:SCCS*=*B9****		SCCS*=*B9****	✓		
	INPUT 10		VXX:SCCS*=*BA****		SCCS*=*BA****	✓		
	AUDIO IN STANDBY OFF		VXX:SCCS*=*A0****		SCCS*=*A0****	✓		
	AUDIO IN STANDBY ON		VXX:SCCS*=*A1****		SCCS*=*A1****	✓		
	QUICK STARTUP OFF		VXX:SCCS*=*A2****		SCCS*=*A2****	✓		
	QUICK STARTUP ON		VXX:SCCS*=*A3****		SCCS*=*A3****	✓		
	AUDIO VOLUME	0		VXX:SCCS*=*C0****		SCCS*=*C0****	✓	
		63		VXX:SCCS*=*FF****		SCCS*=*FF****	✓	
	* PARAMETER1	PROGRAM1		VXX:SCCS1=*****	QVX:SCCS1=**	SCCS1=*****	✓	
		PROGRAM2		VXX:SCCS2=*****	QVX:SCCS2=**	SCCS2=*****	✓	
		PROGRAM3		VXX:SCCS3=*****	QVX:SCCS3=**	SCCS3=*****	✓	
		PROGRAM4		VXX:SCCS4=*****	QVX:SCCS4=**	SCCS4=*****	✓	
	PROGRAM5		VXX:SCCS5=*****	QVX:SCCS5=**	SCCS5=*****	✓		
	PROGRAM6		VXX:SCCS6=*****	QVX:SCCS6=**	SCCS6=*****	✓		
	PROGRAM7		VXX:SCCS7=*****	QVX:SCCS7=**	SCCS7=*****	✓		
* PARAMETER2	COMMAND 1		VXX:SCCS*=01*****	QVX:SCCS*=01	SCCS*=01*****	✓		
	COMMAND 16		VXX:SCCS*=16*****	QVX:SCCS*=16	SCCS*=16*****	✓		
* PARAMETER3	00:00		VXX:SCCS*=***0000		SCCS*=***0000	✓		
	23:59		VXX:SCCS*=***2359		SCCS*=***2359	✓		
STARTUP INPUT SELECT	RGB1		VXX:SISS1=RG1	QVX:SISS1	SISS1=RG1	✓		
	HDMI1		VXX:SISS1=HD1		SISS1=HD1	✓		
	HDMI2		VXX:SISS1=HD2		SISS1=HD2	✓		
	HDMI3		VXX:SISS1=HD3		SISS1=HD3	✓		
	DisplayPort		VXX:SISS1=DP1		SISS1=DP1	✓		
	DIGITAL LINK		VXX:SISS1=DL1		SISS1=DL1	✓		
	LAST USED		VXX:SISS1=LSU		SISS1=LSU	✓		
STARTUP INPUT SELECT (DIGITAL LINK)	LAST USED		VXX:SISI2=+00000	QVX:SISI2	SISI2=+00000	✓		
	INPUT1		VXX:SISI2=+00001		SISI2=+00001	✓		
	INPUT2		VXX:SISI2=+00002		SISI2=+00002	✓		
	INPUT3		VXX:SISI2=+00003		SISI2=+00003	✓		
	INPUT4		VXX:SISI2=+00004		SISI2=+00004	✓		
	INPUT5		VXX:SISI2=+00005		SISI2=+00005	✓		
	INPUT6		VXX:SISI2=+00006		SISI2=+00006	✓		
	INPUT7		VXX:SISI2=+00007		SISI2=+00007	✓		
	INPUT8		VXX:SISI2=+00008		SISI2=+00008	✓		
	INPUT9		VXX:SISI2=+00009		SISI2=+00009	✓		
	INPUT10		VXX:SISI2=+00010		SISI2=+00010	✓		
REMOTE2 - MODE	DEFAULT		VXX:RMPI0=+00000	QVX:RMPI0	RMPI0=+00000	✓		
	USER		VXX:RMPI0=+00001		RMPI0=+00001	✓		
	F/FW SERIES		VXX:RMPI0=+00003		RMPI0=+00003	✓		
REMOTE2 - PIN2	NONE		VXX:RMPS1=P2<NONE	QVX:RMPS1=P2	RMPS1=P2<NONE	✓		
	POWER		VXX:RMPS1=P2<POWER		RMPS1=P2<POWER	✓		
REMOTE2 - PIN3 - 7	* PARAMETER		VXX:RMPS1=P*<*****	QVX:RMPS1=P*	RMPS1=P*<*****	✓		
	* PARAMETER1	PIN3	VXX:RMPS1=P3<*****		RMPS1=P3<*****	✓		
		PIN4	VXX:RMPS1=P4<*****		RMPS1=P4<*****	✓		
		PIN5	VXX:RMPS1=P5<*****		RMPS1=P5<*****	✓		
		PIN6	VXX:RMPS1=P6<*****		RMPS1=P6<*****	✓		
		PIN7	VXX:RMPS1=P7<*****		RMPS1=P7<*****	✓		

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		MZ880 SERIES
				COMMANDS/CALL BACK	COMMANDS	CALL BACK		
PROJECTOR SETUP		* PARAMETER2	NONE	VXX:RMPS1=P*<NONE		RMPS1=P*<NONE		✓
			RGB1	VXX:RMPS1=P*<RGB1		RMPS1=P*<RGB1		✓
			RGB2	VXX:RMPS1=P*<RGB2		RMPS1=P*<RGB2		✓
			HDMI	VXX:RMPS1=P*<HDMI		RMPS1=P*<HDMI		✓
			HDMI1	VXX:RMPS1=P*<HDMI1		RMPS1=P*<HDMI1		✓
			HDMI2	VXX:RMPS1=P*<HDMI2		RMPS1=P*<HDMI2		✓
			HDMI3	VXX:RMPS1=P*<HDMI3		RMPS1=P*<HDMI3		✓
			DIGITAL LINK	VXX:RMPS1=P*<DLINK		RMPS1=P*<DLINK		✓
		REMOTE2 - PIN8	NONE	VXX:RMPS1=P8<NONE	QVX:RMPS1=P8	RMPS1=P8<NONE		✓
			SHUTTER	VXX:RMPS1=P8<SHUTTER		RMPS1=P8<SHUTTER		✓
		FUNCTION BUTTON	DISABLE	OFC:0	QFC	0		✓
			SYSTEM SELECTOR	OFC:1		1		✓
			SYSTEM DAYLIGHT VIEW	OFC:2		2		✓
			SUB MEMORY	OFC:3		3		✓
		DATE AND TIME-DATE SETTING	Year: yyyy	TSD:201506151	QGD	201506161		✓
			Month: mm	TSD:yyyymmddw		yyyymmddw		✓
			Date: dd					✓
			Day:w(1~7:Mon~Sun)					✓
		DATE AND TIME-TIME SETTING	Hour: hh	TST:154503	QGT	154503		✓
			Minute: mm	TST:hmmss		hmmss		✓
			Second: ss					✓
		DATE AND TIME-NTP SYNCHRONIZATION	OFF	VXX:NTPI0=+00000	QVX:NTPI0	NTPI0=+00000		✓
			ON	VXX:NTPI0=+00001		NTPI0=+00001		✓
		LENS TYPE	ET-ELS20	VXX:LNSI6=+00000	QVX:LNSI6	LNSI6=+00000		✓
			ET-ELW21	VXX:LNSI6=+00001		LNSI6=+00001		✓
			ET-ELW22	VXX:LNSI6=+00002		LNSI6=+00002		✓
			ET-ELW20	VXX:LNSI6=+00003		LNSI6=+00003		✓
			ET-ELT22	VXX:LNSI6=+00004		LNSI6=+00004		✓
			ET-ELT23	VXX:LNSI6=+00005		LNSI6=+00005		✓
		LENS CALIBRATION	EXECUTE (ALL)	VXX:LNSI0=+00001				✓
		INITIALIZE-ALL USER DATA	USER INITILIZE	VXX:RSTS1=0password				✓
			USER RESTORE	VXX:RSTS1=1password				✓
		INITIAL START UP	STANDBY	OPY:0	QPY	0		✓
			ON	OPY:1		1		✓
			LAST MEMORY	OPY:2		2		✓
		EMULATE	DEFAULT	VXX:EMUI0=+00001	QVX:EMUI0	EMUI0=+00001		✓
			D3500	VXX:EMUI0=+00002		EMUI0=+00002		✓
			D4000	VXX:EMUI0=+00003		EMUI0=+00003		✓
			D/W5k SERIES	VXX:EMUI0=+00004		EMUI0=+00004		✓
			D/W/Z6k SERIES	VXX:EMUI0=+00005		EMUI0=+00005		✓
			L730	VXX:EMUI0=+00006		EMUI0=+00006		✓
			L780	VXX:EMUI0=+00007		EMUI0=+00007		✓
			L735	VXX:EMUI0=+00008		EMUI0=+00008		✓
			L785	VXX:EMUI0=+00009		EMUI0=+00009		✓
			LB/W SERIES	VXX:EMUI0=+00010		EMUI0=+00010		✓
			F/W SERIES	VXX:EMUI0=+00011		EMUI0=+00011		✓
			LZ370	VXX:EMUI0=+00012		EMUI0=+00012		✓
			VX500 SERIES	VXX:EMUI0=+00013		EMUI0=+00013		✓
			EZ570 SERIES	VXX:EMUI0=+00014		EMUI0=+00014		✓
			VW431D SERIES	VXX:EMUI0=+00015		EMUI0=+00015		✓
		AUDIO SETTING-VOLUME	0	AVL:000	QAV	000		✓
			63	AVL:063		063		✓
		AUDIO SETTING-BALANCE	-16	ABL:-16	QBL	-16		✓
			16	ABL:016		16		✓
		AUDIO SETTING-IN STANDBY MODE	OFF	VXX:ASBI0=+00000	QVX:ASBI0	ASBI0=+00000		✓
			ON	VXX:ASBI0=+00001		ASBI0=+00001		✓
		AUDIO SETTING-IN SHUTTER MODE	OFF	VXX:ASHI1=+00000	QVX:ASHI1	ASHI1=+00000		✓
			ON	VXX:ASHI1=+00001		ASHI1=+00001		✓
		AUDIO SETTING-AUDIO IN SELECT-	AUDIO IN 1	VXX:AINI0=+00000	QVX:AINI0	AINI0=+00000		✓
		AUDIO SETTING-AUDIO IN SELECT-HDMI1	HDMI1 AUDIO IN	VXX:AINI3=+00003	QVX:AINI3	AINI3=+00003		✓
			AUDIO IN 1	VXX:AINI3=+00000		AINI3=+00000		✓
		AUDIO SETTING-AUDIO IN SELECT-HDMI2	HDMI2 AUDIO IN	VXX:AINI7=+00003	QVX:AINI7	AINI7=+00003		✓
			AUDIO IN 1	VXX:AINI7=+00000		AINI7=+00000		✓
		AUDIO SETTING-AUDIO IN SELECT-HDMI3	HDMI3 AUDIO IN	VXX:AINIC=+00003	QVX:AINIC	AINIC=+00003		✓
			AUDIO IN 1	VXX:AINIC=+00000		AINIC=+00000		✓
		AUDIO SETTING-AUDIO IN SELECT-DIGITAL LINK	DIGITAL LINK AUDIO IN	VXX:AINI8=+00005	QVX:AINI8	AINI8=+00005		✓
			AUDIO IN 1	VXX:AINI8=+00000		AINI8=+00000		✓
		FILTER COUNTER-TIMER	OFF	VXX:FCTI1=+00000	QVX:FCTI1	FCTI1=+00000		✓
			1000H	VXX:FCTI1=+01000		FCTI1=+01000		✓
			2000H	VXX:FCTI1=+02000		FCTI1=+02000		✓
			3000H	VXX:FCTI1=+03000		FCTI1=+03000		✓
			4000H	VXX:FCTI1=+04000		FCTI1=+04000		✓
			5000H	VXX:FCTI1=+05000		FCTI1=+05000		✓
			6000H	VXX:FCTI1=+06000		FCTI1=+06000		✓
			7000H	VXX:FCTI1=+07000		FCTI1=+07000		✓
			8000H	VXX:FCTI1=+08000		FCTI1=+08000		✓
			9000H	VXX:FCTI1=+09000		FCTI1=+09000		✓
			10000H	VXX:FCTI1=+10000		FCTI1=+10000		✓
			11000H	VXX:FCTI1=+11000		FCTI1=+11000		✓
			12000H	VXX:FCTI1=+12000		FCTI1=+12000		✓
			13000H	VXX:FCTI1=+13000		FCTI1=+13000		✓
			14000H	VXX:FCTI1=+14000		FCTI1=+14000		✓
			15000H	VXX:FCTI1=+15000		FCTI1=+15000		✓
			15000H	VXX:FCTI1=+16000		FCTI1=+16000		✓
			15000H	VXX:FCTI1=+17000		FCTI1=+17000		✓
			15000H	VXX:FCTI1=+18000		FCTI1=+18000		✓
			15000H	VXX:FCTI1=+19000		FCTI1=+19000		✓
			16000H	VXX:FCTI1=+20000		FCTI1=+20000		✓
		FILTER COUNTER-RESET		VXX:FCTI2=+00000				✓
		MODEL NAME	MODEL NAME		QID	MODELNAME		✓
		SERIAL NUMBER	SW0101234		QSN	SW0101234		✓
		PROJECTOR RUNTIME	7864320H		QVX:RTMS1	RTMS1=7864320		✓
		LAMP1(LIGHT1) RUNTIME	9999H		Q\$L:1	9999		✓
		LIGHT1 RUNTIME	7864320H		QVX:LRTS3=00	LRTS3=00:7864320		✓
		LIGHT STATUS	ALL OFF		QLS	0		✓
		1:ON, 2:OFF			1		✓	
	LAMP(LIGHT) CONTROL STATUS	LAMP OFF		Q\$S	0		✓	
		In turning ON			1		✓	
		LAMP ON			2		✓	
		LAMP Cooling			3		✓	
	AIR FILTER MODEL NUMBER	FILTER MODELNAME		QVX:FMNS0	FMNS0=FIL TERMODELNO		✓	
	AIR FILTER TYPE	NORMAL	MFS:3	QFI:2	0		✓	
		SPECIAL	MFS:4		1		✓	
	FILTER COUNTER	99999H		QFI:0	99999		✓	
	MAC ADDRESS	AB0102030405		QMA	AB0102030405		✓	
	MAIN FIRMWARE VERSION	V1.00.01		QVX:SVRS0	SVRS0=1.00.01		✓	
	INPUT SIGNAL NAME	CHANNEL1 (MAIN CH)		QVX:NSGS1	NSGS1=*****.....		✓	
	DC OUT	OFF	VXX:DCOI1=+00000	QVX:DCOI1	DCOI1=+00000		✓	
		ON	VXX:DCOI1=+00001		DCOI1=+00001		✓	
	TEMPERATURE (INTAKE)	0030/0080		QTM:0	0030/0080		✓	
	TEMPERATURE (EXHAUST AIR)	0030/0080		QTM:1	0030/0080		✓	
	TEMPERATURE (OPTICS MODULE)	0030/0080		QTM:2	0030/0080		✓	
	TEMPERATURE (LIGHT1 / LIGHT1-B)	0030/0080		QTM:11	0030/0080		✓	
	TEMPERATURE (LIGHT2 / LIGHT1-S)	0030/0080		QTM:12	0030/0080		✓	
	LAN data Cloning Write protect	OFF	LCL:WRP0	QCL:WRP	QCL:WRP0		✓	
		ON	LCL:WRP1		QCL:WRP1		✓	
	HDMI-CEC	OFF	SHC:FNC0	QHC:FNC	QHC:FNC0		✓	
		ON	SHC:FNC1		QHC:FNC1		✓	

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL	QUERY		MZ880 SERIES MZ780 MZ680 SMZ58C	
				COMMANDS/CALL BACK	COMMANDS	CALL BACK		
	HDMI-CEC HDMI1 (Change Device)	NEXT PREVIEW		SHC:HM1NXT SHC:HM1PRE			✓ ✓	
	HDMI-CEC HDMI1 (Get Device Name)	DEVICE NAME			QHC:HM1	QHC:HM1DEVICENAME	✓	
	HDMI-CEC HDMI2 (Change Device)	NEXT PREVIEW		SHC:HM2NXT SHC:HM2PRE			✓ ✓	
	HDMI-CEC HDMI2 (Get Device Name)	DEVICE NAME			QHC:HM2	QHC:HM2DEVICENAME	✓	
	HDMI-CEC HDMI3 (Change Device)	NEXT PREVIEW		SHC:HM3NXT SHC:HM3PRE			✓ ✓	
	HDMI-CEC HDMI3 (Get Device Name)	DEVICE NAME			QHC:HM3	QHC:HM3DEVICENAME	✓	
	HDMI-CEC - MENU CODE	0x09 (ROOT)			SHC:MNC1	QHC:MNC	QHC:MNC1	✓
		0x0A (SETUP)			SHC:MNC2		QHC:MNC2	✓
		0x0B (CONTENTS)			SHC:MNC3		QHC:MNC3	✓
		0x0C (FAVORITE)			SHC:MNC4		QHC:MNC4	✓
0x10 (MEDIA TOP)				SHC:MNC5		QHC:MNC5	✓	
0x11 (MEDIA POP UP)				SHC:MNC6		QHC:MNC6	✓	
HDMI-CEC - PROJECTOR -> DEVICE	DISABLE			SHC:PTSOFF	QHC:PTS	QHC:PTSOFF	✓	
	POWER OFF			SHC:PTSPOF		QHC:PTSPOF	✓	
	POWER ON/OFF			SHC:PTSPWR		QHC:PTSPWR	✓	
HDMI-CEC - DEVICE -> PROJECTOR	DISABLE			SHC:STPOFF	QHC:STP	QHC:STPOFF	✓	
	POWER ON			SHC:STPPON		QHC:STPPON	✓	
	POWER ON/OFF			SHC:STPPWR		QHC:STPPWR	✓	
TEST PATTERN	TEST PATTERN	Off		OTS:00	QTS	00	✓	
		White		OTS:01		01	✓	
		Black		OTS:02		02	✓	
		Window		OTS:05		05	✓	
		Reversed Window		OTS:06		06	✓	
		Cross Hatch		OTS:07		07	✓	
		Color Bar V		OTS:08		08	✓	
		Convergence		OTS:11		11	✓	
		Color Bar Side		OTS:51		51	✓	
		16:9/4:3		OTS:59		59	✓	
		Gradation 3		OTS:62		62	✓	
		Gradation 4		OTS:63		63	✓	
	SIGNAL LIST	SIGNAL LIST-REGISTRATION			OEM			✓
SIGNAL LIST-DELETE		A1		ODM:A1			✓	
		A2		ODM:A2			✓	
		A7		ODM:A7			✓	
		A8		ODM:A8			✓	
		L1		ODM:L1			✓	
		L2		ODM:L2			✓	
		L7		ODM:L7			✓	
		L8		ODM:L8			✓	
SUB MEMORY LIST-CHANGEVER		01		OCS:01			✓	
	96		OCS:96			✓		
SUB MEMORY LIST-CHANGEVER (EXTENDED)	01		OCS:01-01			✓		
	96		OCS:95-96			✓		
SUB MEMORY LIST-REGISTRATION			OES			✓		
SUB MEMORY LIST-DELETE	01		ODS:01-01			✓		
	96		ODS:95-96			✓		
SUB MEMORY USAGE STATE	01			QSB	01	✓		
	96				96	✓		
SECURITY	SECURITY SETTING	OFF ON			QVX:SPWI1	SPWI1=+00000 SPWI1=+00001	✓ ✓	
	CONTROL DEVICE SETUP-CONTROL PANEL	DISABLE		VXX:CDSI1=+00000	QVX:CDSI1	CDSI1=+00000	✓	
		ENABLE		VXX:CDSI1=+00001		CDSI1=+00001	✓	
		USER		VXX:CDSI1=+00002		CDSI1=+00002	✓	
	CONTROL DEVICE SETUP-REMOTE CONTROL	DISABLE		VXX:CDSI2=+00000	QVX:CDSI2	CDSI2=+00000	✓	
		ENABLE		VXX:CDSI2=+00001		CDSI2=+00001	✓	
USER			VXX:CDSI2=+00002		CDSI2=+00002	✓		
NETWORK	DIGITAL LINK MODE	AUTO		VXX:DKMI1=+00001	QVX:DKMI1	DKMI1=+00001	✓	
		DIGITAL LINK		VXX:DKMI1=+00002		DKMI1=+00002	✓	
		ETHERNET		VXX:DKMI1=+00003		DKMI1=+00003	✓	
		LONG REACH MODE		VXX:DKMI1=+00004		DKMI1=+00004	✓	
	DIGITAL LINK-DUPLEX(Ethernet)	Auto negotiation		VXX:DKDI1=+00000	QVX:DKDI1	DKDI1=+00000	✓	
		100BaseTX-Full		VXX:DKDI1=+00001		DKDI1=+00001	✓	
		100BaseTX-Half		VXX:DKDI1=+00002		DKDI1=+00002	✓	
	DIGITAL LINK-DUPLEX(DIGITAL LINK)	Auto negotiation		VXX:DKDI2=+00000	QVX:DKDI2	DKDI2=+00000	✓	
		100BaseTX-Full		VXX:DKDI2=+00001		DKDI2=+00001	✓	
		100BaseTX-Half		VXX:DKDI2=+00002		DKDI2=+00002	✓	
	DIGITAL LINK STATUS-LINK	NO LINK			QVX:DKSI1	DKSI1=+00000	✓	
		DIGITAL LINK				DKSI1=+00001	✓	
		LPM				DKSI1=+00002	✓	
		ETHERNET				DKSI1=+00003	✓	
	DIGITAL LINK STATUS-HDCP STATUS	NO SIGNAL			QVX:DKSI2	DKSI2=+00000	✓	
		OFF				DKSI2=+00001	✓	
		ON				DKSI2=+00002	✓	
	DIGITAL LINK STATUS-SIGNAL QUALITY (MIN)	-255 0			QVX:DKSI3	DKSI3=-00255 DKSI3=+00000	✓ ✓	
	DIGITAL LINK STATUS-SIGNAL QUALITY (MAX)	-255 0			QVX:DKSI4	DKSI4=-00255 DKSI4=+00000	✓ ✓	
DIGITAL LINK INPUT CH LIST	HD1:HDMI1,HD2:HDMI2-...			QVX:DL1S1	DL1S1=HD1:HDMI1,****:***	✓		
PROJECTOR NAME SETTING	PROJECTOR1		VXX:NCGS8=PROJECTOR1	QVX:NCGS8	NCGS8=PROJECTOR1	✓		
Art-Net SETUP	OFF		VXX:DANI1=+00000	QVX:DANI1	DANI1=+00000	✓		
	ON(2.*.*)		VXX:DANI1=+00002		DANI1=+00002	✓		
	ON(10.*.*)		VXX:DANI1=+00003		DANI1=+00003	✓		
	ON(MANUAL)		VXX:DANI1=+00004		DANI1=+00004	✓		
Art-Net SETUP-START ADDRESS	1		VXX:DANI3=+00001	QVX:DANI3	DANI3=+00001	✓		
	501		VXX:DANI3=+00501		DANI3=+00501	✓		
Art-Net SETUP-NET	0		VXX:DANI4=+00000	QVX:DANI4	DANI4=+00000	✓		
	127		VXX:DANI4=+00127		DANI4=+00127	✓		
Art-Net SETUP-SUB NET	0		VXX:DANI5=+00000	QVX:DANI5	DANI5=+00000	✓		
	15		VXX:DANI5=+00015		DANI5=+00015	✓		
Art-Net SETUP-UNIVERS	0		VXX:DANI6=+00000	QVX:DANI6	DANI6=+00000	✓		
	15		VXX:DANI6=+00015		DANI6=+00015	✓		
Art-Net SETUP-CHANNEL SETTING	DEFAULT		VXX:DANI8=+00000	QVX:DANI8	DANI8=+00000	✓		
	1		VXX:DANI8=+00001		DANI8=+00001	✓		
	2		VXX:DANI8=+00002		DANI8=+00002	✓		
	USER		VXX:DANI8=+00100		DANI8=+00100	✓		

Note: The commands or parameters with "*" shows available commands or parameters for the projector which has been activated by the Upgrade Kit.